




Position	Code	description
0	573198	INSTRUCTION BOOK
001	708587	BATTERY
002	708577	REAR PANEL
003	708565	BOX
004	NOCODE01	NOT AVAILABLE
005	736175	FOOT
006	5910001800	CONTROL PANEL
007	535582	CONTROL PANEL
008	5385001700	CABLE HOLDER
009	535411	GASKET
010	512971	HEATING ELEMENT
012	511435	THERMOSTAT
013	592335	KNOB
014	521391	KLIXON
016	513128	TILT SWITCH
017	5108007800	LUMINOUS DOUBLE SWITCH
018	5214001400	TIMER
019	732303	WIRE CLAMP