




Position	Code	description
01	CM1081	SIDE LEFT
02	CM1106	THERMOSTAT
03	CM1082	COVER
04	CM1105	SWITCH
05	CM1108	FOOT
06	CM1084	SIDE RIGHT
07	NOCODE01	NOT AVAILABLE
10	CM1101	HEATING ELEMENT
15	CM1087	LED
18	CM1104	SWITCH
19	CM1107	GRID
20	CM1090	GRID UPPER
24	CM1092	POINTER
25	CM1093	DISPLAY
27	CM1095	KNOB
29	CM1102	THERMOSTAT
31	CM1103	POWER SUPPLY CORD