




Position	Code	description
01	5311310721	FOOT
02	5011310311	POWER SUPPLY CORD WITH PLUG (SCHUKO)
03	5312000900	STOP
04	5311310751	THERMOSTAT KNOB
05	5311310761	CHANGE OVER SWITCH KNOB
06	5210810031	THERMOSTAT (75°/250°)
07	5111810871	RED WARNING LIGHT LAMP
08	5111310241	HEATING ELEMENT (2100W/240V) WITH THS(110°)
09	5210910051	3-POSITION CHANGE OVER SWITCH
10	5111310181	TILT SWITCH
11	7011310461	SUPPORT
12	7011310471	SUPPORT