




Position	Code	description
0	573188	INSTRUCTION BOOK
001	708567	GRID
002	NOCODE01	NOT AVAILABLE
003	533443	COVER
005	511958	WARNING LIGHT (220V)
008	590067	KNOB
009	5125105200	SWITCH
012	535661	CONTROL PANEL
013	708568	REAR PANEL
015	521392	THERMOSTAT
016	710341	FRONT PANEL
017	535867	SUPPORT
019	533921	WIRE CLAMP
021	533924	FOOT
023	511435	THERMOSTAT
026	535424	SUPPORT