




Position	Code	description
001	535017	HANDLE
002	535016	SUPPORT
003	707568	REAR PANEL
004	NOCODE01	NOT AVAILABLE
005	512326	HEATING ELEMENT
007	732303	WIRE CLAMP
008	512587	MOTOR
009	535015	FAN
010	707563	GRID
011	534382	GRID
012	512392	THERMOSTAT 130°
013	534785	SLIDER
014	511435	THERMOSTAT
015	AS00006404	GEAR
016	534489	MEASURING SPOON
017	512381	SWITCH
018	5148003500	BIPOLAR SWITCH
019	591689	CONTROL PANEL
020	710276	FRONT PANEL
021	534386	FOOT
022	535338	SUPPORT
023	5214001400	TIMER