




Position	Code	description
0	571457	INSTRUCTION BOOK
001	5108007600	LUMINOUS DOUBLE SWITCH
002	512762	KLIXON
004	511435	THERMOSTAT
006	531503	KNOB
007	531685	HANDLE
008	708793	GRID
013	708826	REAR PANEL
016	531478	FOOT
017	NOCODE01	NOT AVAILABLE
020	535867	SUPPORT
021	533921	WIRE CLAMP
030	710358	FRONT PANEL