




Position	Code	description
0	573188	INSTRUCTION BOOK
001	5108007600	LUMINOUS DOUBLE SWITCH
002	710357	FRONT PANEL
003	512539	SWITCH
004	511435	THERMOSTAT
006	531503	KNOB
007	531685	HANDLE
008	708793	GRID
009	5313001300	FAN
010	5114007900	MOTOR (220/240V 50HZ)
011	702187	DUCT
012	592404	GRID
013	535867	SUPPORT
014	708824	REAR PANEL
015	NOCODE01	NOT AVAILABLE
016	602650	RING
018	521396	KLIXON