




Position	Code	description
000A	5719102700	INSTRUCTION MANUAL
000B	5719102800	INSTRUCTION MANUAL
01	593124	GLASS
02	534075	SPACER
04	709194	CAVITY
08	5219100600	BOARD
11	537329	KEYBOARD
12	536762	KEYBOARD
13	536760	KEYBOARD
14	536796	CLOSURE
15	709183	UPPER HINGE
16	709162	HINGE LOWER
17	NOCODE01	NOT AVAILABLE
18	536384	HOOK
19	612003	SPRING
20	738228	DOOR
21	5319127000	FRAME
22	593092	FRONT PANEL
23	5319119100	HANDLE
24	690512	BASE
25	532710	RUBBER PAD
27	552584	SUPPORT
28	536792	CASTOR
29	NOCODE04	SEE TECHNICAL BULLETIN
30	537301	PULLER
33	536347	RUNNER
37	521466	THERMOSTAT
38	5119108100	MAGNETRON (900W)
40	5119108300	MOTOR
41	537333	SUPPORT
42	521659	BOARD
45	521650	THERMOSTAT 75
46	512999	HEATING ELEMENT (W1000 230V)
48	5119108600	GEARMOTOR (220/240V)
55	536579	FAN JOHNSON
57	NOCODE04	SEE TECHNICAL BULLETIN
58	5319126100	DUCT

62	5119100000	DIODE (-40+130°)
63	5119107500	DIODE (12A)
64	611916	SPRING
65	5119101600	TRANSFORMER
66	5119101800	CAPACITOR (0.95uF)
67	536365	SUPPORT
68	6119102300	SPRING
69	511854	MICROSWITCH MONITOR
70	511855	SECONDARY MICROSWITCH
71	5319143100	CAM
72	536367	CAM