




Position	Code	description
C01	NOCODE01	NOT AVAILABLE
C02	GA1120	MOTOR
C03	GA1121	CONDENSER
C04	NOCODE01	NOT AVAILABLE
C05	GA1123	DIODE
C06	NOCODE01	NOT AVAILABLE
C07	GA1148	MOTOR
C08	GA1126	TRANSFORMER
C09	NOCODE01	NOT AVAILABLE
C10	GA1128	MICROSWITCH
C11	GA1129	MICROSWITCH
C12	GA1130	THERMOSTAT
C13	NOCODE01	NOT AVAILABLE
P01	GA1047	TIMER KNOB
P02	GA1073	CONTROL PANEL
P03	GA1074	HINGE LOWER
P04	NOCODE01	NOT AVAILABLE
P05	GA1076	STOP
P06	NOCODE01	NOT AVAILABLE
P07	GA1078	RUBBER PAD
P08	GA1079	SPONGE
P09	GA1080	RUBBER PAD
P10	NOCODE01	NOT AVAILABLE
P11	GA1082	SUPPORT
P12	GA1083	LEVER
P13	GA1084	SPRING
P14	GA1085	LEVER
P15	GA1086	LEVER
P16	GA1087	SUPPORT
P17	GA1088	ARCHIMEDES' SCREW
P18	GA1089	FAN
P19	GA1090	SPONGE
P20	GA1091	SUPPORT
P21	GA1092	SUPPORT
P22	GA1093	SPRING
P23	GA1094	HOOK
P24	GA1095	FRAME

P25	GA1096	GLASS
P26	GA1097	DOOR
P27	GA1098	COVER
P28	GA1099	INSULATOR
P29	537301	PULLER
P30	GA1101	WASHER
P31	GA1102	CLOSURE
P32	GA1103	HINGE UPPER
P33	GA1104	MICROWAVE CAVITY
P34	NOCODE01	NOT AVAILABLE
P35	GA1106	DUCT
P36	GA1107	SOCKET
P37	NOCODE01	NOT AVAILABLE
P38	GA1109	INSULATOR
P39	GA1110	COVER
P40	GA1111	INSULATOR
P41	NOCODE04	SEE TECHNICAL BULLETIN
P42	GA1113	KNOB
P43	GA1114	SUPPORT
P45	NOCODE01	NOT AVAILABLE
P46	GA1117	RUBBER PAD
P47	GA1118	SPONGE