




Position	Code	description
01	MJ1130	CAVITY
02	MJ1131	CONTROL PANEL
03	MJ1132	KNOB
04	MJ1133	KNOB
05	MJ1134	SUPPORT
06	MJ1135	CASTOR
07	MJ1136	INSULATOR
08	MJ1137	FRAME
09	MJ1138	GLASS
10	MJ1139	DOOR
11	MJ1140	GASKET
12	MJ1141	INNER DOOR
13	MJ1142	SUPPORT BASE
14	MJ1143	FOOT
15	MJ1144	FOOT
16	MJ1145	FOOT
17	MJ1146	RUBBER PAD
18	MJ1147	HOUSING
19	MJ1148	INSULATOR
20	MJ1149	REAR PANEL
21	MJ1150	SUPPORT
22	MJ1151	SUPPORT
23	MJ1152	SUPPORT
24	MJ1153	BRACKET
25	MJ1154	GASKET
27	MJ1155	SUPPORT
28	MJ1156	SUPPORT
29	MJ1157	SPRING
30	MJ1158	RUBBER PAD
31	MJ1159	HOOK
32	MJ1160	SPRING
33	MJ1161	PROTECTION
34	NOCODE04	SEE TECHNICAL BULLETIN
35	MJ1095	INSULATOR
36	MJ1164	COVER
37	MJ1165	FAN
38	MJ1166	PULLER

39	MJ1167	RING
40	MJ1168	GASKET
41	MJ1274	MAGNETRON
42	MJ1170	TRANSFORMER
43	MJ1171	CONDENSER
44	MJ1172	DIODE
45	MJ1173	MOTOR PIVOT L. 28 mm D.3
46	MJ1416	GEARMOTOR
47	MJ1175	TIMER
048A	NOCODE01	NOT AVAILABLE
048B	MJ1356	RES GRILL 500W115V Cm30.7
49	MJ1177	MICROSWITCH
50	MJ1178	MICROSWITCH
51	MJ1179	THERMOSTAT
52	MJ1180	SUPPORT
53	MJ1109	FUSE 0.8A
54	MJ1182	SUPPORT
55	MJ1183	LAMP
56	MJ1184	BOARD
57	MJ1185	SUPPORT LEFT
58	MJ1186	SUPPORT RIGHT
59	MJ1187	POWER SUPPLY CORD
65	MJ1324	LEVER
68	MJ1188	WIRE CLAMP