




Position	Code	description
02	690447	REAR PANEL
03	7019105300	HOUSING
05	5319153800	INSULATOR
07	709157	CAVITY
08	5919137900	CONTROL PANEL
09	611900	SPRING
11	5919137700	KNOB
12	5919137100	TIMER KNOB
13	512818	WARNING LIGHT
14	536380	CLOSURE
15	NOCODE01	NOT AVAILABLE
16	709162	HINGE LOWER
17	5319163200	FRAME
18	536384	HOOK
19	612003	SPRING
20	7419155100	DOOR ASSEMBLY
21	5319140300	FRAME
22	5919120400	FRONT PANEL
23	5319140400	HANDLE
24	690448	BASE
25	532710	RUBBER PAD
27	536289	SUPPORT WITHOUT WHEELS
28	535762	CASTOR
29	NOCODE04	SEE TECHNICAL BULLETIN
30	535127	PULLER
31	6119100200	GRID
32	6119105200	GRID
33	536347	RUNNER
35	5311811071	LENS
37	521466	THERMOSTAT
38	5119108100	MAGNETRON (900W)
39	521659	BOARD
40	5119108300	MOTOR
41	5319164300	ARCHIMEDES SCREW
45	5219101000	THERMOSTAT 125
47	513134	HEATING ELEMENT (W1400 225V)
48	5119108600	GEARMOTOR (220/240V)

53	521658	CHANGE OVER SWITCH
54	521656	TIMER
55	536579	FAN JOHNSON
57	NOCODE04	SEE TECHNICAL BULLETIN
60	536482	SUPPORT
61	5219109900	CURRENT LIMITER
62	5119100000	DIODE (-40+130°)
63	5119107500	DIODE (12A)
64	611916	SPRING
65	5119102900	TRANSFORMER
66	5119109200	CAPACITOR 1uF
67	536365	SUPPORT
68	6119102300	SPRING
69	511854	MICROSWITCH MONITOR
70	511855	SECONDARY MICROSWITCH
71	5319143100	CAM
72	536367	CAM