




Position	Code	description
01	690446	REAR PANEL
02	536652	INSULATOR
04	536878	INSULATOR
05	5319128500	INSULATOR
06	536599	INSULATOR
07	7019100000	CAVITY
08	5919126700	CONTROL PANEL
09	611900	SPRING
13	512818	WARNING LIGHT
14	536380	CLOSURE
15	NOCODE01	NOT AVAILABLE
16	709162	HINGE LOWER
17	5319163200	FRAME
18	7319123300	HOOK
19	612003	SPRING
20	7419155100	DOOR ASSEMBLY
21	5319117700	FRAME
22	5919127100	FRONT PIECE
23	5319117600	HANDLE
24	6919105600	BASE
25	532710	RUBBER PAD
26	NOCODE04	SEE TECHNICAL BULLETIN
27	536289	SUPPORT WITHOUT WHEELS
28	535762	CASTOR
29	NOCODE04	SEE TECHNICAL BULLETIN
30	535127	PULLER
31	6119100200	GRID
32	6119100100	GRID
33	536347	RUNNER
34	536684	LENS
35	5311811071	LENS
36	6119105200	GRID
37	5219101600	SAFETY THERMOSTAT (145°C)
38	5119108100	MAGNETRON (900W)
39	521659	BOARD
40	5119108300	MOTOR
41	536788	ARCHIMEDES SCREW

42	612017	SPRING
43	5111910011	UPPER HEATING ELEMENT (304/47V)
44	5111910001	LOWER HEATING ELEMENT (271/178V)
45	521466	THERMOSTAT
46	5119105900	MOTOR
47	513134	HEATING ELEMENT (W1400 225V)
49	521660	THERMOSTAT
50	534180	CAM
51	534179	LEVER
53	521657	CHANGE OVER SWITCH
55	536579	FAN JOHNSON
56	536683	GASKET
57	611874	SPRING
58	612007	SPRING
59	612008	ROD
60	536482	SUPPORT
61	5219109900	CURRENT LIMITER
62	5119100000	DIODE (-40+130°)
63	5119107500	DIODE (12A)
64	611916	SPRING
65	5119102900	TRANSFORMER
66	5119109200	CAPACITOR 1uF
67	536365	SUPPORT
68	6119102300	SPRING
69	511854	MICROSWITCH MONITOR
70	511855	SECONDARY MICROSWITCH
71	5319143100	CAM
72	536367	CAM