




Position	Code	description
000A	573884	INSTRUCTION BOOK
000B	573885	INSTRUCTION BOOK
01	593124	GLASS
02	690447	REAR PANEL
03	NOCODE01	NOT AVAILABLE
04	709157	CAVITY
05	536758	KNOB
06	611900	SPRING
07	593099	CONTROL PANEL
08	5219100600	BOARD
09	5019516500	POTENTIOMETER
10	5219100700	MEMBRANE
11	536764	KEYBOARD
12	536761	KEYBOARD
13	536760	KEYBOARD
14	536380	CLOSURE
16	709162	HINGE LOWER
17	5319163200	FRAME
18	536384	HOOK
19	612003	SPRING
20	7419155100	DOOR ASSEMBLY
22	592982	FRONT PANEL
23	5319117100	HANDLE
24	690448	BASE
25	532710	RUBBER PAD
26	5319153800	INSULATOR
27	536289	SUPPORT WITHOUT WHEELS
28	535762	CASTOR
29	NOCODE04	SEE TECHNICAL BULLETIN
30	535127	PULLER
31	6119100200	GRID
32	6119105200	GRID
33	536347	RUNNER
37	521466	THERMOSTAT
38	512983	MAGNETRON WITH PINS
39	521659	BOARD
40	5519126300	FAN MOTOR ASSEMBLY

41	5319164300	ARCHIMEDES SCREW
45	5219101000	THERMOSTAT 125
47	513134	HEATING ELEMENT (W1400 225V)
48	5119108600	GEARMOTOR (220/240V)
55	536578	FAN (PLASET)
57	NOCODE04	SEE TECHNICAL BULLETIN
62	5119100000	DIODE (-40+130°)
63	5119107500	DIODE (12A)
64	611916	SPRING
65	5119102900	TRANSFORMER
66	5119101400	CAPACITOR (1.05µF)
67	536365	SUPPORT
68	6119102300	SPRING
69	511854	MICROSWITCH MONITOR
70	511855	SECONDARY MICROSWITCH
71	5319143100	CAM
72	536367	CAM