




Position	Code	description
000A	573884	INSTRUCTION BOOK
000B	573885	INSTRUCTION BOOK
01	593124	GLASS
02	690447	REAR PANEL
03	709340	HOUSING
04	709157	CAVITY
05	537326	KNOB
06	611900	SPRING
07	593274	CONTROL PANEL
08	5219100600	BOARD
09	5019516500	POTENTIOMETER
10	5219100700	MEMBRANE
11	537324	KEYBOARD
12	537323	KEYBOARD
13	537322	KEYBOARD
14	536380	CLOSURE
15	NOCODE01	NOT AVAILABLE
16	709162	HINGE LOWER
17	5319163200	FRAME
18	536384	HOOK
19	612003	SPRING
20	7419155100	DOOR ASSEMBLY
21	537327	FRAME
22	592982	FRONT PANEL
23	537328	HANDLE
24	690448	BASE
25	532710	RUBBER PAD
26	5319153800	INSULATOR
27	536289	SUPPORT WITHOUT WHEELS
28	535762	CASTOR
29	NOCODE04	SEE TECHNICAL BULLETIN
30	535127	PULLER
31	6119100200	GRID
32	6119105200	GRID
33	536347	RUNNER
37	521466	THERMOSTAT
38	512983	MAGNETRON WITH PINS

39	521659	BOARD
40	5519126300	FAN MOTOR ASSEMBLY
41	5319164300	ARCHIMEDES SCREW
45	5219101000	THERMOSTAT 125
47	513134	HEATING ELEMENT (W1400 225V)
48	5119108600	GEARMOTOR (220/240V)
55	536578	FAN (PLASET)
57	NOCODE04	SEE TECHNICAL BULLETIN
62	5119100000	DIODE (-40+130°)
63	5119107500	DIODE (12A)
64	611916	SPRING
65	5119102900	TRANSFORMER
66	5119101400	CAPACITOR (1.05μF)
67	536365	SUPPORT
68	6119102300	SPRING
69	511854	MICROSWITCH MONITOR
70	511855	SECONDARY MICROSWITCH
71	5319143100	CAM
72	536367	CAM