




Position	Code	description
01	690446	REAR PANEL
02	536652	INSULATOR
04	536878	INSULATOR
05	5319128500	INSULATOR
06	536599	INSULATOR
07	709158	CAVITY
08	5219101500	BOARD
09	5019516500	POTENTIOMETER
10	5219102400	MEMBRANE
11	5319107200	KEYBOARD
12	536761	KEYBOARD
13	536760	KEYBOARD
14	5919115200	GLASS
15	5919115100	CONTROL PANEL
16	611900	SPRING
17	NOCODE04	SEE TECHNICAL BULLETIN
18	536758	KNOB
19	5219100000	FEELER
20	536384	HOOK
21	612003	SPRING
22	7419155100	DOOR ASSEMBLY
25	592982	FRONT PANEL
26	5319117100	HANDLE
27	709162	HINGE LOWER
28	5319163200	FRAME
29	NOCODE01	NOT AVAILABLE
30	536347	RUNNER
31	536380	CLOSURE
32	532710	RUBBER PAD
33	690448	BASE
34	MJ1322	LOW GRID
35	6119100200	GRID
36	6119105200	GRID
37	535127	PULLER
38	NOCODE04	SEE TECHNICAL BULLETIN
39	535762	CASTOR
40	536289	SUPPORT WITHOUT WHEELS

42	5119108100	MAGNETRON (900W)
43	521659	BOARD
44	5319164300	ARCHIMEDES SCREW
45	5519126300	FAN MOTOR ASSEMBLY
47	537421	SUPPORT
48	5111910011	UPPER HEATING ELEMENT (304/47V)
49	521466	THERMOSTAT
50	5111910001	LOWER HEATING ELEMENT (271/178V)
51	5119105900	MOTOR
52	513134	HEATING ELEMENT (W1400 225V)
53	5119108600	GEARMOTOR (220/240V)
54	5119107500	DIODE (12A)
55	5119100000	DIODE (-40+130°)
56	536683	GASKET
57	536578	FAN (PLASET)
58	611916	SPRING
59	5119101400	CAPACITOR (1.05µF)
60	511854	MICROSWITCH MONITOR
61	6119102300	SPRING
62	536365	SUPPORT
63	5319143100	CAM
64	511855	SECONDARY MICROSWITCH
65	536367	CAM
66	5119102900	TRANSFORMER
67	612008	ROD
68	612028	SPRING
69	537312	PULLER
70	5119100200	THERMOREGULATOR
71	537313	BLOCK