




Position	Code	description
0	NOCODE01	NOT AVAILABLE
001	534075	SPACER
002	707104	HOUSING
003	708798	CAVITY
006	690340	BASE
007	533677	FOOT
008	532710	RUBBER PAD
009	708796	HINGE
010	534322	WASHER
011	708797	HINGE
012	534103	FRAME
014	534065	FRAME
015	592358	GLASS
016	534105	HOOK
017	534104	HOOK
019	611743	ROD
020	611742	SPRING
021	534067	HANDLE
025	534038	DUCT
026	611771	SPRING
027	611747	SPRING
028	534041	CAM
029	611749	SPRING
030	534042	LEVER
031	611748	SPRING
032	534043	SLIDER
033	534040	SUPPORT
035	592373	GLASS
037	534254	KEYBOARD
038	611750	SPRING
040	534305	KEY
041	534044	LEVER
049	535762	CASTOR
050	5519117700	PLATE
051	552427	SUPPORT
052	534286	PULLER
053	5119108600	GEARMOTOR (220/240V)

054	535744	SUPPORT
055	511854	MICROSWITCH MONITOR
057	511855	SECONDARY MICROSWITCH
058	5119109300	FUSE (8A)
059	521661	BOARD
063	5119108700	TRANSFORMER
064	512983	MAGNETRON WITH PINS
065	521466	THERMOSTAT
070	NOCODE04	SEE TECHNICAL BULLETIN
071	5119107500	DIODE (12A)
072	5119100000	DIODE (-40+130°)
073	5119108500	FILTER
075	5119101400	CAPACITOR (1.05μF)
076	535748	FAN
077	5519126300	FAN MOTOR ASSEMBLY
080	535743	STIRRER COVER