







Position	Code	description
001	534075	SPACER
002	707102	HOUSING
003	690155	REAR PANEL
004	535104	INSULATOR
006	534048	LENS
007	512162	WARNING LIGHT
008	611750	SPRING
009	707883	CAVITY
011	735337	KNOB
012	735338	KNOB
014	735339	KNOB
016	534046	KEY
017	534047	PUSH BUTTON
018	690157	BASE
019	690272	PANEL
020	533677	FOOT
021	532710	RUBBER PAD
022	690271	SUPPORT
024	534322	WASHER
026	534183	FRAME
027	534165	GASKET
028	734063	DOOR
029	534066	FRAME
030	592133	GLASS
031	534105	HOOK
033	611743	ROD
034	611742	SPRING
035	534068	HANDLE
036	611771	SPRING
037	534063	ARCHIMEDES SCREW
039	690195	PARABOLA
040	534037	DUCT
041	534163	GASKET
042	533429	GLASS
043	611747	SPRING
044	534041	CAM
045	611749	SPRING

046	534042	LEVER
047	611748	SPRING
048	534043	SLIDER
049	534040	SUPPORT
052	534044	LEVER
053	591980	CONTROL PANEL
054	534104	HOOK
066	5519117700	PLATE
067	535048	SUPPORT
068	521382	THERMOSTAT
069	535020	PULLER
070	5119108600	GEARMOTOR (220/240V)
071	512153	MOTOR
072	534182	FAN
074	5119101400	CAPACITOR (1.05 μ F)
075	5119107500	DIODE (12A)
076	535762	CASTOR
077	9827000550	RING
078	5119108700	TRANSFORMER
079	512983	MAGNETRON WITH PINS
080	685274	SUPPORT
082	534186	HOOK
084	521466	THERMOSTAT
087	611850	GRID
089	511854	MICROSWITCH MONITOR
090	511855	SECONDARY MICROSWITCH
092	5119100000	DIODE (-40+130°)
093	601850	BRACKET
094	NOCODE04	SEE TECHNICAL BULLETIN
095	534035	SUPPORT
096	521135	BOARD
097	534134	FOOT
098	521297	CHANGE OVER SWITCH
099	521515	THERMOSTAT
100	NOCODE01	NOT AVAILABLE