







Position	Code	description
0	572957	INSTRUCTION BOOK
001	534075	SPACER
002	707102	HOUSING
003	690155	REAR PANEL
004	535104	INSULATOR
006	534048	LENS
007	512162	WARNING LIGHT
008	611750	SPRING
009	707884	CAVITY
012	734408	KNOB
014	734410	KNOB
015	690191	REAR PANEL
016	534046	KEY
017	534047	PUSH BUTTON
018	690157	BASE
019	690272	PANEL
020	533677	FOOT
021	532710	RUBBER PAD
022	690271	SUPPORT
024	534322	WASHER
026	534183	FRAME
027	534165	GASKET
029	534066	FRAME
030	592133	GLASS
031	534105	HOOK
033	611743	ROD
034	611742	SPRING
035	534068	HANDLE
036	611771	SPRING
037	534063	ARCHIMEDES SCREW
039	690195	PARABOLA
040	534037	DUCT
041	534163	GASKET
042	533429	GLASS
043	611747	SPRING
044	534041	CAM
045	611749	SPRING

046	534042	LEVER
047	611748	SPRING
048	534043	SLIDER
049	534040	SUPPORT
050A	534306	PANEL
050B	NOCODE01	NOT AVAILABLE
052	534044	LEVER
053	591991	CONTROL PANEL
054	534104	HOOK
055	534049	LENS
067	690170	FAN
068	521382	THERMOSTAT
069	534175	PULLEY
070	534173	BELT
072	534164	FAN
073	535300	CLOSURE
074	5119101400	CAPACITOR (1.05μF)
075	5119107500	DIODE (12A)
076	5519117700	PLATE
077	535048	SUPPORT
082	534186	HOOK
083	5119108600	GEARMOTOR (220/240V)
084	535020	PULLER
087	611850	GRID
089	511854	MICROSWITCH MONITOR
090	511855	SECONDARY MICROSWITCH
092	5119100000	DIODE (-40+130°)
094	611752	SPRING
095	521480	THERMOSTAT
097	534180	CAM
098	521357	CHANGE OVER SWITCH
099	534179	LEVER
100	521393	TIMER
101	521515	THERMOSTAT
102	534035	SUPPORT
103	NOCODE04	SEE TECHNICAL BULLETIN
104	601850	BRACKET
105	521466	THERMOSTAT

106	512983	MAGNETRON WITH PINS
107	5119108700	TRANSFORMER
108	534134	FOOT
109	521135	BOARD
110	534176	PULLEY
112	511816	TCO (226°)
113	T20877	SUPPORT
114	9813751316	SCREW
115	535762	CASTOR
116	9827000550	RING