




Position	Code	description
0	BF1015	TUBE
01	BF1000	GRID
02	5512110251	ANALYZER
03	BF1001	FRAME
04	BF1002	3-PLATE BURNER
05	BF1003	REAR CASTOR
06	BF1004	CONTROL PANEL
07	BF1005	VALVE
08	BF1006	LIGHTER
09	BF1007	TAP KNOB
10	BF1011	3-INJECTOR KIT WITH SUPPORTS
11	BF1012	FRONT CASTOR