




Position	Code	description
01	7012110181	FRONT PIECE
02	7012310051	GRID
03	7023000000	PARABOLA
04	5523000100	BURNER
05	5321000600	REAR PANEL
06	6223000200	TUBE
07	6212310051	ANALYZER COCK TUBE
08	552552	ANALYZER
09	5521001300	TAP
11	7023000100	PARABOLA
12	6221000600	INJECTOR
15	5312110081	KNOB
16	5912110041	CONTROL PANEL
17	6223000300	TUBE
18	602576	WASHER
19	9816100826	NUT (M8)
20	602214	PIN
21	5510001000	CASTOR
22	7312110261	REAR CASTOR
23	7021003400	BASE
26	7021004400	SEPARATOR