




Position	Code	description
01	7012310091	GRID
02	5912310011	CONTROL PANEL
04	5312110081	KNOB
05	7112310061	FRONT PANEL
08	5512310021	VALVE WITH THERMOCOUPLE
09	7312310118	BURNER
10	552552	ANALYZER
11	7012310021	SIDES ASSEMBLY
12	7012310011	REAR PANEL
13	7012110121	BASE
14	5510001000	CASTOR
15	7312110261	REAR CASTOR