




Position	Code	description
0	5525114400	Conf. 3 Oil Filter + 3 Vapor + 3 Odor
01	5325154900	LEFT HINGE
02	6125103700	SPRING
03	6125103600	SPRING
04	5325154800	RIGHT HINGE
06	5325134100	GRID
07	5325143100	COVER
08	5325133800	GLASS
09	6925104200	BOTTOM OF COVER
10	5325143500	GASKET
11	7325124700	COVER
12	5325144000	SPACER
13	5325143900	SPACER
14	5325104700	SPACER
16	5525105300	HOOK
17	6125104100	SPRING
18	5325143800	CASING
19	536330	BRUSH
20	7325125800	VESSEL WITH HEATING ELEMENT (1800W/230V)
21	5325133900	BLOCK
22	9824800015	CLIP CLAMP (18.70-18.20-17.70)
23	5512500089	OIL DRAIN TUBE
24	5325120600	STOPPER
25	5213219131	TCO (15A 216°)
27	5525105700	BASE
29	532233	RUBBER PAD
30	5325106400	BUSH
31	5325135600	COVER
32	7025102100	BASKET
36	7312573089	HANDLE
37	5225101600	THERMOSTAT
38	5325135100	SUPPORT
39	5925115500	CONTROL PANEL
42	5325139400	KEY
43	5325151000	THERMOSTAT KNOB
44	9824800014	CLIP CLAMP (9.30-9.10-8.80)
45	NOCODE01	NOT AVAILABLE

46	5325143200	BUSH
47	5325136000	EXTENSION
48	5125105200	SWITCH
49	513116	WARNING LIGHT
50	5311811071	LENS
51	5325139500	DOOR
53	5225100200	TIMER WITH BATTERY (99')
54	5325135700	PROTECTION
55	5325135200	PUSH BUTTON
56	5325149600	PROTECTION