




Position	Code	description
0	573414	INSTRUCTION BOOK
001	NOCODE01	NOT AVAILABLE
003	708574	CASING
004	533856	PEDESTAL
005	552223	BOTTOM
006	592691	CONTROL PANEL
009	592692	COVER
010	690091	INNER COVER
013	611278	SPRING
015	532203	CLOSURE
018	535115	CLOSURE
020	737041	COVER
021	735665	HANDLE
022	732029	BASKET
026	602650	RING
027	533736	EXTENSION
028	511587	WARNING LIGHT (220V)
029	5125105200	SWITCH
031	533921	WIRE CLAMP
032	5512500149	GEARMOTOR
033	622063	PIN
034	532509	CLIP CLAMP
035	532524	GASKET
036	532233	RUBBER PAD
039	621574	PROTECTION