




| Position | Code       | description        |
|----------|------------|--------------------|
| 0        | 5725100100 | INSTRUCTION MANUAL |
| 01       | 536330     | BRUSH              |
| 05       | 534703     | GASKET             |
| 08       | 7325103500 | HANDLE             |
| 09       | 5512500019 | BASKET ASSEMBLY    |
| 10       | 534992     | TRAY               |
| 11       | 534993     | SUPPORT            |
| 12       | 685244     | PAN                |
| 13       | 611780     | SPRING             |
| 14       | 611782     | PIN                |
| 16       | 536784     | HOOK               |
| 18       | 622068     | PROTECTION         |
| 19       | 5525104400 | FRAME              |
| 20       | 592752     | DOOR               |
| 22       | 591707     | STOPPER            |
| 24       | 591657     | PUSH BUTTON        |
| 25       | 5125100000 | WARNING LIGHT LAMP |
| 26       | 591655     | SLIDER             |
| 27       | 5125105200 | SWITCH             |
| 29       | 552583     | BOTTOM             |
| 30       | 536256     | GEAR               |
| 31       | 512284     | THERMOSTAT         |
| 32       | 5325120600 | STOPPER            |
| 33       | 535235     | TUBE (L215)        |
| 34       | 532509     | CLIP CLAMP         |
| 35       | 532524     | GASKET             |
| 36       | 622063     | PIN                |
| 37       | 534574     | BUSH               |
| 38       | 5512500149 | GEARMOTOR          |
| 39       | 532233     | RUBBER PAD         |
| 40       | 511816     | TCO (226°)         |
| 41       | NOCODE01   | NOT AVAILABLE      |
| 44       | 611779     | SPRING             |