




Position	Code	description
01	AS00001320	THERMOSTAT KNOB
02	611900	SPRING
03	AS00001321	COVER
04	5312515641	UPPER PART COVER
05	5312515781	FRONT PIECE
06	5912510981	DELONGHI LOGO
07	AS00000926	SUPPORT
08	AS00000927	POTENTIOMETER
15	5112510981	SWITCH
16	5212510601	TIMER
22	AS00002897	LOWER COVER
23	AS00001586	MOTOR
25	5312514201	RUBBER PAD
26	6012510271	FAN
27	5312516201	SPRING
28	6012510721	SPRING
29	AS00000922	LID SUPPORT SET
32	5312515761	COVER
33	5912510911	TIMER KNOB
34	5112511011	HEATING ELEMENT (1400W 240V)
35	6012510691	FAN
36	AS00001322	BAND
37	5312516111	STOPPER
38	7312581059	BASKET
39	AS00001336	VESSEL WITH HEATING ELEMENT (H=80mm 240V 300W)
40	5312515871	SUPPORT
43	6112510731	SPRING
44	5312515851	KEY
45	5312515411	FOOT
46	6012510641	GRID
47	6112510751	SPRING
50	6112510721	PIN
51	5212510181	SAFETY THERMOSTAT (150°C)
52	6012510351	BRACKET
53	5312513041	MICROSWITCH SUPPORT
54	5112510341	MICROSWITCH WITH LEVER

55	AS00001323	WARNING LIGHT/TCO WIRING
56	5312515401	RUBBER PAD
57	AS00000931	WIRE CLAMP
58	5312515881	CLOSURE
59	5012574009	POWER SUPPLY CORD WITH PLUG (UK)
60	AS00001325	POWER PCB
61	AS00000933	BOARD SUPPORT
62	5212510651	SENSOR (NTC)
63	6012510341	SUPPORT
64	AS00001326	TCO WIRING