




Position	Code	description
01	5325174900	GRID
04	5325173800	COVER
05	5325175100	GLASS
06	5325173900	STOP
07	6025104100	RUNNER
08	5325174400	CLOSURE
09	5325129100	TUBE
10	7312574449	HANDLE
12	6125102400	LEVER SUPPORT
13	6125101200	BUSH
14	5325174000	KEY
15	5325174200	HANDLE LOWER
16	5325174300	SLIDER
17	5325174100	HANDLE UPPER
18	611472	SPRING
19	6125104300	SPRING
20	5225103200	THERMOSTAT 250°
21	5325176100	SEAT
23	5325177000	EXTENSION
25	5325175800	CASTOR
26	5325175700	SLIDER
27	9824600001	RING
28	5325175400	CLOSURE
29	5325176000	SLIDER
30	5325175900	EXTENSION
32	5325175300	SUPPORT
33	6225105400	THERMOSTAT SENSOR
34	6225101900	SENSOR
35	5225101800	TCO
36	5925124400	CONTROL PANEL
37	5225100200	TIMER WITH BATTERY (99')
38	5325174800	PUSH BUTTON
39	5325174700	SUPPORT
40	5311811071	LENS
43	5125105200	SWITCH
44	532233	RUBBER PAD
46	5325106300	BUSH

47	5325176900	CLOSURE
48	7312574629	WIRING LAMP
49	5525113000	BASE
50	6125103400	SPRING
53	5325172300	KEY
54	5112510171	MICROSWITCH WITH LEVER
55	6025107600	BRACKET
56	5325172800	CONTAINER
57	5325171800	SPACER
58	5325171700	SPACER LEFT
59	5325171600	SPACER RIGHT
60	6925107900	CONTAINER
63	5125104800	HEATING ELEMENT
65	501422	POWER SUPPLY CORD
66	7025107400	EXTRACTABLE PAN
67	7025107100	BASKET
68	5325175000	GASKET
69	6925107500	INNER COVER
70	5325113000	RIGHT HINGE
71	6125102500	SPRING
73	6125101900	PIN
74	6125102600	SPRING
75	5325112900	LEFT HINGE
76	7325140700	COVER