




Position	Code	description
01	5312512061	SPACER
02	5312511081	SPACER
03	5912510211	CASING
04	6112510341	SPRING
05	6112510171	SPRING
06	5312511021	KEY
07	7312577729	BASKET
08	7312577699	VESSEL ASSEMBLY WITH HEATING ELEMENT
09	5312512131	SPACER
13	5312511031	BOTTOM
14	5312511271	COVER FILTER GRID
15	5312511171	ACTIVATED CARBON FILTER
17	5312511351	GLASS
18	6112510131	SPRING
19	5312512231	COVER HINGE
20	5312511181	SUPPORT
21	7312576849	COVER ASSEMBLY
22	5012573669	POWER SUPPLY CORD WITH PLUG (SCHUKO)
24	5312511011	BASE
25	532233	RUBBER PAD
26	5512500239	CONTROLS ASSEMBLY
27	5312511341	KNOB
28	5312511321	GASKET