




Position	Code	description
01	5325164900	FILTER GRID
03	5325165100	GASKET
04	6025106300	INNER COVER
05	5325165000	GLASS
06	6025107200	SUPPORT
07	5225103000	THERMOSTAT 220
08	6125106500	SUPPORT
09	6225103900	FLANGE
10	5325111200	GASKET
11	5325130500	CLIP CLAMP
12	5325168300	SEAT
15	5225100800	TCO
16	6225108600	TCO SENSOR
17	6225105400	THERMOSTAT SENSOR
18	6125106600	SUPPORT
20	5325168000	CAM
21	5325167900	EXTENSION
22	5325167800	JOINT
23	5225103400	THERMOSTAT (240V 13.5A 149°C)
24	9826800017	SPRING
25	5512500159	HEATING ELEMENT (1800W230V)
26	5125105000	GEARMOTOR
28	6025101700	WASHER
29	6125101500	SPRING
30	5112510171	MICROSWITCH WITH LEVER
31	6025107100	BRACKET
32	6225102400	NUT
33	6225102200	DRAGGER
34	5325112200	WASHER
35	6225104000	PIN
36	532524	GASKET
37	7312576079	VESSEL ASSEMBLY
38	7312574109	POWER SUPPLY CORD
40	5325163500	BOTTOM
41	5325106300	BUSH
42	532233	RUBBER PAD
43	5325163300	PEDESTAL

45	5325164400	SUPPORT
46	5325167700	THERMOSTAT KNOB
47	5311811071	LENS
48	5925122700	CONTROL PANEL
49	7312574169	LAMP
50	5325173100	CLOSURE RIGHT
51	5325164000	CLOSURE
52	5925123300	CASING
53	5125105200	SWITCH
54	5325168100	SUPPORT
56	6125106200	SPRING
57	5325163200	SPACER
58	6125106100	SPRING
59	5325161800	RIGHT HINGE
60	5325163100	SPACER LEFT
61	6125106000	PIN
62	5325161900	LEFT HINGE
63	7312576149	HANDLE
64	7312572969	BASKET
65	NOCODE04	SEE TECHNICAL BULLETIN
66	611779	SPRING
67	5325162900	SUPPORT
68	5325163000	SPACER
69	5225100200	TIMER WITH BATTERY (99')
70	5325162000	PUSH BUTTON
71	5325162300	DOOR
72	5325162100	CLOSURE
73	5325163800	CONTROL PANEL
74	5325164500	PUSH BUTTON
75	5325164300	FRONT PIECE