




Position	Code	description
01	5325113100	COVER
02	5325113600	GRID
03	5325115200	GLASS
04	5325112900	LEFT HINGE
05	6125102600	SPRING
06	6125101900	PIN
07	6125102500	SPRING
08	5325113000	RIGHT HINGE
09	6925101700	INNER COVER
10	7325111300	COVER
11	7325111000	PAN
12	7025100700	BASKET
13	5525100000	HANDLE
14	5225100900	THERMOSTAT (250°C)
15	5213219131	TCO (15A 216°)
16	5325113900	SPACER
17	5325114000	SPACER
18	5325104700	SPACER
19	5325113400	CASING
20	6125102300	SPRING
21	NOCODE01	NOT AVAILABLE
22	5325113700	KEY
23	5525101800	PEDESTAL
24	532233	RUBBER PAD
25	5925110200	CONTROL PANEL
26	513116	WARNING LIGHT
27	5311811071	LENS
29	5325106400	BUSH