




Position	Code	description
01	5325113100	COVER
02	5325113600	GRID
03	5325115200	GLASS
04	5325112900	LEFT HINGE
05	6125102600	SPRING
06	6125101900	PIN
07	6125102500	SPRING
08	5325113000	RIGHT HINGE
09	6925101700	INNER COVER
10	7325111300	COVER
11	7325113100	PAN
12	7025100700	BASKET
13	5525100000	HANDLE
14	5225100900	THERMOSTAT (250°C)
15	511816	TCO (226°)
16	5325113900	SPACER
17	5325114000	SPACER
18	5325104700	SPACER
19	5325120400	CASING
20	6125103400	SPRING
21	5325130900	SUPPORT
22	5325130600	PUSH BUTTON
23	5525102400	PEDESTAL
24	532233	RUBBER PAD
25	5925110900	CONTROL PANEL
26	513116	WARNING LIGHT
27	5311811071	LENS
29	5325106400	BUSH