




Position	Code	description
001	5325112900	LEFT HINGE
002	6125103100	SPRING
003	6125100400	PIN
004	6125103000	SPRING
005	5325113000	RIGHT HINGE
006	5325101500	FILTER GRID
007	5325101300	COVER
008	5325114800	GLASS
009	6925102700	BOTTOM OF COVER
010	5325146700	GASKET
011	7325118200	COVER
012	5325104100	SPACER
013	5325102200	SPACER
014	5325101800	SPACER
016	5525100200	HOOK
017	6125100800	SPRING
018	5325127400	CASING
020	7312576119	PAN
021	5525101200	BLOCK
022	5225102200	BOARD
023	5112510171	MICROSWITCH WITH LEVER
024	6125107300	SUPPORT
025	6225101900	SENSOR
026	5525103700	NTC PROBE
027	5525108300	PEDESTAL
028	5225100800	TCO
029	611912	SPRING
030	5325106300	BUSH
031	5325147400	BOTTOM
032	5512500019	BASKET ASSEMBLY
033	5512500159	HEATING ELEMENT (1800W230V)
034	9826800017	SPRING
035	6225102200	DRAGGER
036	7312576029	IMPUGNATURA
037	6125101500	SPRING
038	5225100200	TIMER WITH BATTERY (99')
039	5925113100	CONTROL PANEL

040	5325129200	PUSH BUTTON
041	5325111400	SUPPORT
042	5325107100	PUSH BUTTON
043	5325140400	KNOB
044	6025101700	WASHER
046	5325104000	BUSH
047	5325126400	EXTENSION
048	5125105200	SWITCH
050	5311811071	LENS
052	6225103900	FLANGE
053	5325111200	GASKET
054	532524	GASKET
055	6225104000	PIN
056	5325130500	CLIP CLAMP
057	5325112200	WASHER
058	6225102400	NUT
059	5125105000	GEARMOTOR