




Position	Code	description
001	5325112900	LEFT HINGE
002	6125100300	SPRING
003	6125100400	PIN
004	6125103000	SPRING
005	5325113000	RIGHT HINGE
006	5325105200	FILTER GRID
007	5325105100	COVER
009	NOCODE01	NOT AVAILABLE
010	5325146700	GASKET
011	7312576139	COVER
012	5325104800	SPACER
013	5325104900	SPACER
014	5325104700	SPACER
016	5525100200	HOOK
017	6125100800	SPRING
018	5325127400	CASING
019	536330	BRUSH
020	7325136000	PAN
021	5525101300	BLOCK
022	9824800015	CLIP CLAMP (18.70-18.20-17.70)
023	5512500089	OIL DRAIN TUBE
024	5325120600	STOPPER
025	511816	TCO (226°)
026	6225101200	STOP
027	5525108300	PEDESTAL
029	611912	SPRING
030	5325106400	BUSH
031	5325147400	BOTTOM
032	5512500019	BASKET ASSEMBLY
036	7312576029	IMPUGNATURA
037	5225103800	THERMOSTAT
039	5925109300	CONTROL PANEL
040	5325104600	KEY
043	5325140400	KNOB
044	9824800014	CLIP CLAMP (9.30-9.10-8.80)
045	5325103900	BUSH
046	5325104000	BUSH

047	5325102600	EXTENSION
048	5125105200	SWITCH
049	513116	WARNING LIGHT
050	5311811071	LENS
051	5925106400	DOOR
052	6225101300	FLANGE
053	5325111100	GASKET
054	532524	GASKET
055	622063	PIN
056	532509	CLIP CLAMP
057	9821002346	WASHER (D1-21)
058	9815002086	NUT (M20X1.5)
059	5512500149	GEARMOTOR