




Position	Code	description
000A	5313270059	GASKET FOR HEATING ELEMENT
000B	5332180400	SLIDING BLOCK BLACK(PA66)
000C	IT1000	PORTABLE DIGITAL THERMOMETER (-50°C +150°C)
000D	AS00000378	ECOMULTICLEAN 10ML VIAL
002	552071	COVER
003	5332170400	SUPPORT
004	7313282099	WATER TANK
005	534629	STOPPER
006	5332112100	BALL
007	534554	CONTROL PANEL
008	591672	CONTROL PANEL
009	53132C8134	MEASURING SPOON
010	607836	SMALL 1-CUP FILTER
011	607731	LARGE 2-CUP FILTER
012	534714	LEVER
013	734432	SUMP
014	534622	VESSEL
016	534381	PRESSING DEVICE
017	5532126400	BOTTOM
018	534213	FOOT
019	5332159900	COVER
020	533544	WIRE CLAMP
021	710194	CABINET
022	535018	CUP HOLDER
024	5313217771	O-RING
025	NOCODE01	NOT AVAILABLE
026	551926	TAP
027	552075	KNOB
028	707477	TUBE
029	621969	NUT
031	521137	MANOMETER
032	534840	TUBE
033	535708	FROTHER
034	690196	BRACKET
036	5118100800	WARNING LIGHT LAMP
038	532723	Push Button Grey

039	591708	PUSH BUTTON
040	5132100800	BIPOLAR SWITCH (16A 125/250V)
041	5132100700	UNIPOLAR SWITCH (16A 125/250V)
042	5332289700	VALVE
044	6113211931	SPRING
045	611761	DIFFUSER
046	621964	DOWEL
047	611775	SPRING
048	534783	TUBE (L80)
049	534632	FILTER
050	734564	SUPPORT
051	534552	SUPPORT
052	707116	SUPPORT
053	533218	GASKET
054	6832101000	LOWER BOILER
055	534774	TUBE
056	5113270612	PUMP (230V)
057	535790	AUTOPRIMER
058	621988	CONNECTION
059	534781	TUBE (L170)
060	534848	SUPPORT
061	511816	TCO (226°)
062	5513200799	HEATING ELEMENT WITH GASKET
063	533216	GASKET
064	6813210411	UPPER BOILER
065	9850081500	WASHER
066	7032103100	CONNECTION
068	621968	NUT
069	621967	NOSE
070	621970	RING
071	534710	GASKET
072	5232101300	SAFETY THERMOSTAT (125°C+-3.5K)
073	512709	THS (95°)