




Position	Code	description
000A	9811040850	SCREW (M4X8)
000B	5313270059	GASKET FOR HEATING ELEMENT
000C	9815002850	STAINLESS STEEL NUT (M10 X 1.25) BOILER/VALVE
000D	9815003750	STAINLESS STEEL NUT (M8 X 1) BOILER/CONNECTION
000E	5332180400	SLIDING BLOCK BLACK(PA66)
000F	IT1000	PORTABLE DIGITAL THERMOMETER (-50°C +150°C)
000G	AS00000378	ECOMULTICLEAN 10ML VIAL
002	53132C8134	MEASURING SPOON
003	5513215011	STEAM KNOB
005	5013275239	TCO WITH WIRING AND LAMP
006	5013275249	WIRING WITH LAMP
007	5913213801	CONTROL PANEL
008	6113210081	SPRING (H6)
009	5513215001	CHANGE OVER SWITCH KNOB
011	5113210871	SWITCH (250V)
012	5313224111	PUSH BUTTON COVER
013	5113210841	CHANGE OVER SWITCH (16A 250V)
014	7313278259	STEAM VALVE
015	5232101300	SAFETY THERMOSTAT (125°C+-3.5K)
016	5232100600	SAFETY THERMOSTAT (105°C+-2K)
017	536281	TUBE
019	533216	GASKET
020	5132109400	HEATING ELEMENT (1000W/100V)
023	6032101200	FILTER
024	7313285849	GASKET
030	AS00000942	QUICK CONNECT CONNECTION
031	6132101300	SPRING
032	5313217701	O-RING (D=3.85 T=2)
033	5513220521	IMPURITY FILTER
035	534848	SUPPORT
036	5132107100	PUMP
037	5532146000	TUBE
038	AS00009453	ANTI-DRIP VALVE
040	536321	TUBE
043	7313284869	WATER TANK

045	5332148400	VALVE
046	621986	RING
047	6213210451	COMPRESSION DOWEL
049	6113211931	SPRING
051	5332120500	SPACER
052	535733	JOINT
053	5332120200	STOP
054	5332120700	BLOCK
055	535789	FROTHER
056	5332117200	PRESSING DEVICE
057	6113210481	TUBE
058	5332284700	CUP HOLDER
059	5332284600	CUP HOLDER TRAY
060	5313224721	RUBBER FOOT PAD
061	5013275259	POWER SUPPLY CORD WITH PLUG (JP)
062	5332266600	FLOAT
064	9824800009	CLIP CLAMP (8.30-8.10-7.80)
070	7313280779	FILTER HOLDER SUMP
071	5332173200	DUCT
072	6032101800	FILTER
073	5332117600	GASKET
074	534714	LEVER
075	6032109900	Large two-cup filter
076	6032109800	1-DOSE FILTER
077	7313275999	POD FILTER HOLDER SUMP (ILLY)
078	5213215591	BOARD (100-240V)