




Position	Code	description
000A	9811040850	SCREW (M4X8)
000B	5313270059	GASKET FOR HEATING ELEMENT
000C	9815002850	STAINLESS STEEL NUT (M10 X 1.25) BOILER/VALVE
000D	9815003750	STAINLESS STEEL NUT (M8 X 1) BOILER/CONNECTION
000E	IT1000	PORTABLE DIGITAL THERMOMETER (-50°C +150°C)
000F	AS00000378	ECOMULTICLEAN 10ML VIAL
002	53132C8134	MEASURING SPOON
003	5513215011	STEAM KNOB
005	5013275019	TCO WITH WIRING AND LAMP
006	5013275029	WIRING WITH LAMP
007	5913213801	CONTROL PANEL
008	6113210081	SPRING (H6)
009	5513215001	CHANGE OVER SWITCH KNOB
011	5113211491	PUSH BUTTON
012	5313236251	PUSH BUTTON COVER
013	5113210841	CHANGE OVER SWITCH (16A 250V)
015	5232101300	SAFETY THERMOSTAT (125°C+-3.5K)
016	5232100600	SAFETY THERMOSTAT (105°C+-2K)
017	536281	TUBE
018	7313271239	STEAMER
023	6032107100	FILTER
024	7313285849	GASKET
031	6132101300	SPRING
032	5313217701	O-RING (D=3.85 T=2)
033	5513220521	IMPURITY FILTER
034	5332122800	SILICON HOSE (DI=4 L35)
035	534848	SUPPORT
036	5113270612	PUMP (230V)
037	5532146000	TUBE
038	AS00009453	ANTI-DRIP VALVE
040	5313220001	TUBE (L315)
041	5332125200	SILICON HOSE (DI=4 L110)
043	7313284869	WATER TANK
045	5332148400	VALVE
046	621986	RING

047	6213210451	COMPRESSION DOWEL
049	6113211931	SPRING
051	5332120500	SPACER
052	535733	JOINT
053	5332120200	STOP
055	535789	FROTHER
056	5332117200	PRESSING DEVICE
057	6113210481	TUBE
058	5332284700	CUP HOLDER
059	5332284600	CUP HOLDER TRAY
060	5313224721	RUBBER FOOT PAD
061	5013276699	POWER SUPPLY CORD WITH PLUG (GB)
062	5332266600	FLOAT
063	5313234311	BOTTOM
064	9824800009	CLIP CLAMP (8.30-8.10-7.80)
070	7313280779	FILTER HOLDER SUMP
074	534714	LEVER
075	AS00001314	LARGE 2-CUP FILTER
076	AS00001313	SMALL 1-CUP OR POD FILTER
078	5213216471	PCB