





ELC4



Position	Code	description
000A	9811040850	SCREW (M4X8)
000B	5332173200	DUCT
000C	6032102600	FILTER
000D	9815002850	STAINLESS STEEL NUT (M10 X 1.25) BOILER/VALVE
000E	9815003750	STAINLESS STEEL NUT (M8 X 1) BOILER/CONNECTION
000F	5332180400	SLIDING BLOCK BLACK(PA66)
000G	IT1000	PORTABLE DIGITAL THERMOMETER (-50°C +150°C)
000H	AS00000378	ECOMULTICLEAN 10ML VIAL
001	5332102300	COVER
002	7332107900	TRAY
003	536196	SUPPORT
004	536199	SLIDER
005	738531	REGULATOR
006	5313217741	O-RING (D=6.75 T=1.78)
007	536372	GASKET
008	5332102100	MIXER
009	5332159200	COVER
010	5332102400	COVER
011	537398	HOOK
012	611924	SPRING
013	5532100600	COVER
014	7132101700	BODY
015	533544	WIRE CLAMP
016	7313282099	WATER TANK
017	534629	STOPPER
018	5332112100	BALL
019	5332102600	BOTTOM
020	5932100700	CONTROL PANEL
021	7313285859	FROTH DISPENSER FILTER
022	6032102400	2-DOSE FILTER
023	7313285889	FILTER FASTENER
024	6032101800	FILTER
025	5332117600	GASKET
026	7332122300	FILTER HOLDER PODS UNIVERSAL
027	7332173100	FILTER HOLDER SUMP

028	534714	LEVER
029	53132C8134	MEASURING SPOON
030	5332160400	PAN
031	709090	CUP PLATE
033	534213	FOOT
034	5513233861	BRUSH
036	5132100900	PUMP (230-240V 50HZ 16W)
037	536281	TUBE
038	5532111900	TUBE / 2 BUSHES (PTFE DI2-DE4 L=100)
039	534801	PRESSING DEVICE
040	536321	TUBE
041	511855	SECONDARY MICROSWITCH
043	5232100600	SAFETY THERMOSTAT (105°C+-2K)
044	621968	NUT
045	621967	NOSE
046	AS00000942	QUICK CONNECT CONNECTION
047	9850081500	WASHER
048	511816	TCO (226°)
049	5232100700	SOLENOID VALVE (230/50)
050	6832103900	UPPER BOILER
051	537200	CONNECTION
052	537407	CONNECTION
053	536497	TUBE
054	534632	FILTER
055	533216	GASKET
056	5132109600	HEATING ELEMENT
057	6832101000	LOWER BOILER
058	5132100800	BIPOLAR SWITCH (16A 125/250V)
059	5132100700	UNIPOLAR SWITCH (16A 125/250V)
060	534499	BLACK KEY
063	5118100800	WARNING LIGHT LAMP
064	NOCODE01	NOT AVAILABLE
065	7313277679	ORANGE WARNING LIGHT
066	5313217701	O-RING (D=3.85 T=2)
067	6032101200	FILTER
068	533218	GASKET
069	7032101500	SUPPORT
070	5332289700	VALVE

071	621986	RING
072	6113211931	SPRING
073	536370	INSULATOR
074	622371	CONNECTION
075	521523	THS (150°)
076	537211	TUBE
077	5332100000	GENERATOR OUTLET TUBE
078	521540	THS (315°)
079	NOCODE04	SEE TECHNICAL BULLETIN
080	7332118400	GENERATOR
081	5113270612	PUMP (230V)
082	5332122800	SILICON HOSE (DI=4 L35)
083	534848	SUPPORT
084	AS00009453	ANTI-DRIP VALVE
085	6232103400	DOWEL
086	621970	RING
090	5313210661	CUP HOLDER TRAY
091	5532126400	BOTTOM
092	532233	RUBBER PAD