

























Position	Code	description
000A	ES0061431	Bellow bottle (702 cpl)
000B	FL36322	GASKET
000C	AS00000378	ECOMULTICLEAN 10ML VIAL
01	FL36151	BODY
02	FL36199	RUNNER
03	FL30318	CLIP
04	FL360612	PUMP
05	FL36183	PUMP SUPPORT
06	FL36136	TUBE
07	FL36026	MOTOR
0009	FL361982	SUPPORT BASE
009A	AS00009676	BASE
10	FL38149	FOOT
12	FL36312	CLAMP (230V)
13	FL36C082	WIRING
14	FL36127	GEAR
15	FL41001	FLOWMETER
17	FL36200	COVER
19	FL366002	COVER
20	FL36601	BODY COVER
21	FL36243	PUSH BUTTON
23	FL3601	LEVER WIRING
24	FL36218	PCB
26	FL36602	UPPER BODY
27	FL36504	LEVER
29	FL36180	PCB
33	FL36217	SPRING
37	FL36034	ROTOR
40	FL36042	GEAR
41	FL36174	BRACKET
42	FL36173	BRACKET
43	FL36221	COVER
44	FL36219	COVER
45	FL363092	SPRING
46	FL363091	SPRING
47	FL36144	COVER
48	FL363081	SPRING

49	FL363082	SPRING
50	FL360382	UPPER BODY
51	FL36172	RUNNER
52	FL362113	LEFT SIDE
53	FL36149	INSULATOR
54	FL362992	SUPPORT
56	FL36310	STICKER
57	FL36186	COVER
58	FL3602	MAIN WIRING
59	FL36084	PCB
62	FL36189	PCB FLOW METER WITH WIRING
63	FL36302	COFFEE OUTLET
64	FL36214	FRONT PIECE
65	FL36301	FASTENER
66	FL36300	LEVER
67	FL3618	MAIN WIRING TO SWITCH
68	FL36C192	MAIN WIRING TO LIMITER (230V)
69	FL36152	BODY
70	FL36153	GEAR
71	FL36502	GRID
72	FL12356568	TRAY
73	FL36500	TRAY
74	FL361772	PCB (230V)
75	FL36178	COVER
79	FL360302	MOTOR
80	FL36163	TUBE
82	FL36133	CLAMP
83	FL36070	WATER TANK (LOW END)
87	FL36164	TUBE
88	FL362103	RIGHT SIDE
089A	AS00009678	SENSOR
89	FL36096	SUPPORT
90	AS00000740	FILTER
91	FL36168	DELIVERY TUBE
92	FL36262	BALL
93	FL36266	WATER TANK CONNECTOR
94	FL36311	COVER
95	FL36268	SUPPORT

96	FL36C122	POWER SUPPLY CORD
99	FL36260	CONTAINER