










Position	Code	description
000A	5332111500	TUBE (DI=7 DE=10 L=120)
000B	5332115400	SILICONE HOSE (DI=5 L=145)
000C	5313283911	TUBE
000D	5032514800	FLOWMETER WIRING (L 470)
000E	5332186200	DRAIN HOSE (90°L180)
000F	5332224100	MOTOR BELT
000G	5332238300	DRAIN HOSE (90° L=180)
000H	AS13200107	COVER ASSEMBLY
000I	5332164700	RUNNER FRAME
000J	5313212371	BICCHIERE EROGATORE(ABS)NERO ESAM03
000K	5313215891	SCUFF-PROOF RUBBER PAD
000L	5513211891	SCRAPER BRUSH WITH BRISTLES
000M	6113210111	FIXING BRACKET (TCO)
000N	6113210121	SENSOR BRACKET
000O	5313219181	GRINDER BELLOW GASKET
000P	6913210021	SOLENOID VALVE SUPPORT (2V)
000Q	6913210031	SOLENOID VALVE SUPPORT (3V)
000R	6913210011	POD SUPPORT
000S	6932103900	GRID
000T	5313239751	GRINDER PANEL
000U	5013257331	CABLING WITH FUSE (1.25 A)
000V	5313240551	TUBE (SIL PLAT)DI=3 DE=5.5 L17
000W	AS00000378	ECOMULTICLEAN 10ML VIAL
000X	5332261200	GASKET
000Y	6913210111	FRONT BRACKET DEGREASED ESAM69
001	5332143500	COVER
002	5332143400	COVER
004	5332262600	COVER
005	5332143900	LEFT SIDE
006	5913210471	GRINDING ADJUSTMENT KNOB
007	5532146600	TANK
008	5313218991	REAR PANEL
009	5332143800	RIGHT SIDE
010	5213212291	BOARD
011	NOCODE04	SEE TECHNICAL BULLETIN
012	7313220731	DOOR ASSEMBLY
013	5332142600	HOOK

014	5313251481	WATER TANK COVER
015	AS13200255	WATER TANK
016	5313214841	WATER TANK FRONT PIECE
017	6013210441	CUP HOLDER
018	5313214961	CUP HOLDER TRAY
019	5332225000	BOTTOM
020	5332266600	FLOAT
021	5313214901	CONTROL KNOB
022	5332249000	KNOB PLATE
023A	AS00000621	ELECTRONIC CONTROL BOARD
023B	AS13200050	CONTROL BOARD
027	7313222121	CONTROL PANEL ASSEMBLY
029	5513222541	STEAM KNOB
030	6013213181	FILTER (D.40X2.3 TAI-FENG)
031	5332149100	O-RING
032	7313251441	INFUSER
033A	5013251401	TCO WITH WIRING
033B	5013251931	TCO WITH WIRING
034	5513227971	GRINDER ASSEMBLY (2D-DL 230V)
0035	5313284261	SUPPORT
036	6132104700	SPRING (x micro 12 x 5)
037	5132105700	MICROSWITCH
038	7332166600	SLIDER
039	5332142400	BUSH
040	5332142300	BUSH
042	5313217751	O-RING BLACK (D=6.07 T=1.78)
043	5332213000	PIN
044	5332148400	VALVE
045	6132106900	SPRING
046	5313276531	GASKET
047	5332139200	FILTER
049	5113210421	MICROSWITCH
050	5132110500	MICROSWITCH (250V 85°)
051	5213213971	HALL SENSOR (L620)
052	5313243071	TOOTHED BELT
053A	7313226071	TRANSMISSION KIT (ECM)
053B	7313243951	TRANSMISSION KIT (CHIAPHUA)
054	6132101300	SPRING

055	5313217701	O-RING (D=3.85 T=2)
056	5313216501	PUMP SUPPORT
057	7313219421	SAFETY VALVE
058	5213211161	PUMP PROTECTOR
059	5113270612	PUMP (230V)
060	534848	SUPPORT
061	5232104600	REED SENSOR
062	AS13200036	POWER BOARD (SW1.1 230V)
063	5132105400	MICROSWITCH (10A/ 250V/ 125°)
064	5513230831	FLOW REGULATOR
065	5013251401	TCO WITH WIRING
066	5013251931	TCO WITH WIRING
068	5313228791	GENERATOR GASKET
069	5332239300	SPACER
070	5313218931	RIGHT ANGLE GENERATOR CONNECTION
071	5332239200	CONNECTOR
072	5213225251	FLOWMETER
073	5513236251	BOILER (230V)
074	6113213191	CLIP (WIRE 1,2 AISI302)
075A	7313217261	MOTOR WITH PULLEY (ECM 230V)
075B	7313249421	MOTOR ASSEMBLY (CHIAPHUA 230V)
076A	5213212381	MOTOR BOARD (ECM 230V)
076B	AS00000614	MOTOR BOARD
077	6113213191	CLIP (WIRE 1,2 AISI302)
078	5332239200	CONNECTOR
079	5313228791	GENERATOR GASKET
080	5513220521	IMPURITY FILTER
081	5513213801	TUBE WITH 2 BUSHES (L180)
082	5332142600	HOOK
083	5313219281	O-RING (D=13.1 T=2.62)
084	5332169300	LOWER TUBE
085	AS13200007	MECHANICS VALVE (ESAM)
086	5513213801	TUBE WITH 2 BUSHES (L180)
087	AS13200138	FROTHER
088	5332144800	O-RING (D=6)
089	5513213181	FROTHER TUBE
090	5313219271	O-RING (D11 91 T2.62)
091	535693	GASKET (D=9,25 T=1,78)

092	AS00008426	TUBE
093	5113210421	MICROSWITCH
094	5332139800	LEVER
095	6132103500	SPRING
096	9812631250	SCREW (3.5X12)
097	5313277681	STOPPER
098	53132C9532	FROTH DEVICE VALVE NATURAL(PSU)ESAM&ECAM
099	6132112200	SPRING
100	9824800014	CLIP CLAMP (9.30-9.10-8.80)