





ATTENZIONE: Prima di ordinare i ricambi verificare la sigla posta sull'etichetta caratteristica. Se presente (CM) ordinare i ricambi con riferimento A


ATTENTION: please, check Serial Number before you order spare parts. If on the label you read CM (as you can see in the above photo) you will have to order spares indicated by letter A.




25



26



36



27

28

29


30

31

32

33

34



35

37


38



39

40


41
















42





66





85
SERIE TUBI
TUBE SERIES

SERIE TUBI CON BOCCOLE
TUBE SERIES WITH BUSHES

Position	Code	description
000A	5313213841	FROTHER STOP
000B	533135	GASKET (D=7,66 T=1,78)
000C	53132C8134	MEASURING SPOON
000D	NOCODE04	SEE TECHNICAL BULLETIN
000E	NOCODE04	SEE TECHNICAL BULLETIN
000F	5032111900	POWER SUPPLY CORD WITH PLUG (SCHUKO)
000G	5313256701	GENERATOR COVER
000H	5313213291	HOSE COUPLING COVER
000I	5332224100	MOTOR BELT
000J	5013251461	WIRING FOR FLOWMETER (L300)
000K	5313213411	DOOR
000L	5513211891	SCRAPER BRUSH WITH BRISTLES
000M	6113210111	FIXING BRACKET (TCO)
000N	6113210121	SENSOR BRACKET
000O	5313235921	TANK GASKET
000P	5313219181	GRINDER BELLOW GASKET
000Q	SER0354	GREASE TUBE (5GR VERKOFOOD)
000R	5313213451	COFFEE HOSE CLAMP
000S	AS00006031	GRINDER FINGER STOP RING
000T	IT1000	PORTABLE DIGITAL THERMOMETER (-50°C +150°C)
000U	5013257371	CABLING WITH FUSE FOR GRINDER (1.25A L=450mm)
000V	AS00000378	ECOMULTICLEAN 10ML VIAL
000W	6013211721	PLATE
001	5313213711	GROUND COFFEE TANK COVER
001A	5313221031	GROUND COFFEE TANK COVER
002	5513214151	COFFEE BEANS TANK COVER
002A	AS00010434	COFFEE BEANS COVER
003	7313227461	UPPER COVER
003A	7313224811	UPPER COVER
004	5313213421	GRIND REGULATION INDICATOR
004A	5913212611	GRIND REGULATION KNOB
005	5513222561	REAR PANEL
006	5513217011	LEFT SIDE
007B	AS13200343	COFFEE BEANS TANK
07AA	AS00001792	COFFEE BEANS TANK

07AB	5313213461	TANK
008	5313213721	BEANS COVER HINGE
009	AS00006115	SWITCH HOLDER
010	5513217001	RIGHT SIDE
011	AS00009990	DLS-COVER TANK SMOKE(C8-11)(SAN) ECAM
012	AS13200250	TANK
012A	AS00010091	WATER TANK
013	5313218571	WATER TANK FRONT PIECE
014	AS00008460	DLS-CONT COF.GROUNDS BK(ABS)+BAG ECAM37
015	5313218501	FRONT PIECE
016	6013216181	CUP HOLDER
017	AS13200099	DRIP TRAY
018	5313222641	FLOAT
019	5132112500	SWITCH
020	5313215181	COFFEE GROUNDS CONTAINER FRONT
021	5313213551	DRAIN TRAY
025	7313222241	CONTROL PANEL ASSEMBLY WITH BOARD
026	5513212491	BOARD
027	5313213911	COFFEE OUTLET TANK COVER
028	5313213901	COFFEE OUTLET TANK
029	6132106200	SPRING
030	5332227400	REGULATOR
031	5313213881	GUIDE DISPENSER COVER
032	5313215321	DISPENSER HANDLE
033	5313215311	CONVEYOR EXTERNAL PART
034	9812631250	SCREW (3.5X12)
035	AS00008315	STEAM VALVE
036	5513222431	STEAM KNOB
037	5313215291	FROTHER COVER
038	7313214601	FROTHER
039	53132D0730	O RING
040	5313217751	O-RING BLACK (D=6.07 T=1.78)
041	5313214361	FROTHER INTERNAL TUBE
042	5513213741	FROTHER TUBE
047	AS00008952	REED SENSOR
048	5213216661	POWER BOARD (SW1.3 230V)
049	532233	RUBBER PAD
054	7313251451	INFUSER

055	6113210131	SPRING
056	5313213241	EXPULSION LEVER RUBBER PAD
057	5313213191	EXPULSION LEVER
059	6013213181	FILTER (D.40X2.3 TAI-FENG)
060	5313277681	STOPPER
061	53132C9532	FROTH DEVICE VALVE NATURAL(PSU)ESAM&ECAM
062	6132112200	SPRING
064	5313213211	BOTTOM PISTON
065	5313210401	FINGER STOP COVER (B)
065A	5313227651	FINGER STOP COVER
066	7313227621	GRINDER ASSEMBLY (2D-DL 230V)
066A	AS00002955	GRINDER ASSEMBLY
071	5313213591	TROLLEY SLEWING RING
072	AS00006298	TROLLEY
073	7313295821	COMPENSATION SYSTEM
074	5313213431	GASKET
075	5513228021	TRANSMISSION ASSEMBLY (ECM 230V)
076	AS00008306	DLS-PCB FILTER MOTOR(GDS-CN)230V ECAM
077	5132110500	MICROSWITCH (250V 85°)
078	7313217261	MOTOR WITH PULLEY (ECM 230V)
079	5213213971	HALL SENSOR (L620)
080	AS00009034	TOOTHED BELT
081	5313236711	RIGHT ANGLE WATER OUTLET TUBE (90° L=190)
082	5132104100	MICROSWITCH (250V 85°)
083	5313238581	GASKET
084	5313217601	BLACK FILTER
085	5513227961	MECHANICS VALVE (DLS ECAM)
086A	5313217861	TUBE (DI=3 DE=5,5 L145)
086B	5313217871	TUBE (DI=3 DE=6 L200)
086C	5332199500	SILICONE HOSE (DI=4 DE=8 L=150)
087A	5513212871	TUBE WITH 2 BUSHES (L97)
087B	5513212881	TUBE WITH 2 BUSHES (L270)
087C	5513212891	TUBE WITH 2 BUSHES (L230)
087D	5513212901	TUBE WITH 2 BUSHES (L290)
088	5313217701	O-RING (D=3.85 T=2)
089	6132101300	SPRING
090	5113270613	PUMP (230V)

091	5513230831	FLOW REGULATOR
092	5313230671	PUMP SUPPORT
093	5213211181	SENSOR (NTC)
094	5332239300	SPACER
095	5313228791	GENERATOR GASKET
096	6113213191	CLIP (WIRE 1,2 AISI302)
097	7313219401	SAFETY VALVE
098	5113210211	MICROSWITCH
099	5213225251	FLOWMETER
100	5332239200	CONNECTOR
101	5213211161	PUMP PROTECTOR
102	5513236251	BOILER (230V)
103	5013251391	TCO WITH WIRING
104	5013251401	TCO WITH WIRING
105	5513214661	CAM SLIDER