






























66





85
SERIE TUBI
TUBE SERIES

86
SERIE TUBI CON BOCCOLE
TUBE SERIES WITH BUSHES

87
88

Position	Code	description
000A	5313224911	FROTHER GASKET
000B	5513211891	SCRAPER BRUSH WITH BRISTLES
000C	SER0354	GREASE TUBE (5GR VERKOFOOD)
000D	AS00006031	GRINDER FINGER STOP RING
000E	AS00000378	ECOMULTICLEAN 10ML VIAL
000F	6013211721	PLATE
000Z	AS00010041	FROTHER TUBE
00DD	53132C8177	RUBBER PAD TROLLEY ECAM
001	5313221031	GROUND COFFEE TANK COVER
002	AS00010434	COFFEE BEANS COVER
003	7313222201	UPPER COVER
004	5913212611	GRIND REGULATION KNOB
005	5513222561	REAR PANEL
006	5513217011	LEFT SIDE
007	AS13200343	COFFEE BEANS TANK
009	5313230851	KEY SUPPORT
010	5513217001	RIGHT SIDE
011	AS00009990	DLS-COVER TANK SMOKE(C8-11)(SAN) ECAM
012	AS13200250	TANK
012A	AS00010091	WATER TANK
013	5313218571	WATER TANK FRONT PIECE
014	AS13200103	COFFEE GROUNDS CONTAINER
015	5313218521	FRONT PIECE
016	AS00008346	CUP HOLDER
017	AS13200099	DRIP TRAY
018	5313222641	FLOAT
019	5113211621	SWITCH (16A 125/250V)
021	5313213551	DRAIN TRAY
025	7313221121	CONTROL PANEL ASSEMBLY WITHOUT BOARD
026	AS00010040	PCB LED
027	5313213911	COFFEE OUTLET TANK COVER
028	5313213901	COFFEE OUTLET TANK
029	6132106200	SPRING
030	5332227400	REGULATOR
031	5313223051	DISPENSER COVER
032	53132C8172	DISPENSER
033	5313217741	O-RING (D=6.75 T=1.78)

034	9812631250	SCREW (3.5X12)
035	AS13200086	STEAM VALVE ASSEMBLY
036	AS00008493	DLS-KNOB STEAM CHROMED+SPRING(AISI) ECAM
037	AS13200144	DISPLAY GLASS
038	AS00006121	TUBE WITH FROTHER
039	53132D0730	O RING
040	5313217751	O-RING BLACK (D=6.07 T=1.78)
041	5332169300	LOWER TUBE
042	5313221171	FROTHER EXTERNAL TUBE
047	AS00008952	REED SENSOR
048	AS13200148	POWER BOARD (SW2.2 230V)
049	532233	RUBBER PAD
050	5313213841	FROTHER STOP
054	7313251451	INFUSER
055	6113210131	SPRING
056	5313213241	EXPULSION LEVER RUBBER PAD
057	5313213191	EXPULSION LEVER
058	9812631250	SCREW (3.5X12)
059	6013213181	FILTER (D.40X2.3 TAI-FENG)
060	5313277681	STOPPER
061	53132C9532	FROTH DEVICE VALVE NATURAL(PSU)ESAM&ECAM
062	6132112200	SPRING
063	5313238581	GASKET
064	5313213211	BOTTOM PISTON
066	AS00002955	GRINDER ASSEMBLY
070	9812631250	SCREW (3.5X12)
071	5313213591	TROLLEY SLEWING RING
072	AS00006298	TROLLEY
073	7313295821	COMPENSATION SYSTEM
074	5313213431	GASKET
075	AS00005636	TRANSMISSION (CHIAPHUA 230V)
076	AS00000614	MOTOR BOARD
077	5132110500	MICROSWITCH (250V 85°)
078	7313249421	MOTOR ASSEMBLY (CHIAPHUA 230V)
079	5213213971	HALL SENSOR (L620)
080	5313243071	TOOTHED BELT

081	5313236711	RIGHT ANGLE WATER OUTLET TUBE (90° L=190)
082	5132104100	MICROSWITCH (250V 85°)
083	5313238581	GASKET
084	5313217601	BLACK FILTER
085	5513227961	MECHANICS VALVE (DLS ECAM)
086A	5313217861	TUBE (DI=3 DE=5,5 L145)
086B	5313217871	TUBE (DI=3 DE=6 L200)
086C	5332199500	SILICONE HOSE (DI=4 DE=8 L=150)
087A	5513212871	TUBE WITH 2 BUSHES (L97)
087B	5513212881	TUBE WITH 2 BUSHES (L270)
087C	5513212891	TUBE WITH 2 BUSHES (L230)
087D	5513212901	TUBE WITH 2 BUSHES (L290)
088	5313217701	O-RING (D=3.85 T=2)
089	6132101300	SPRING
090	5113270613	PUMP (230V)
091	5513230831	FLOW REGULATOR
092	5313230671	PUMP SUPPORT
093	5213211181	SENSOR (NTC)
094	5332239300	SPACER
095	5313228791	GENERATOR GASKET
096	6113213191	CLIP (WIRE 1,2 AISI302)
097	7313219401	SAFETY VALVE
098	5113210211	MICROSWITCH
099	5213225251	FLOWMETER
100	5332239200	CONNECTOR
101	5213211161	PUMP PROTECTOR
102	5513236251	BOILER (230V)
103	5013251391	TCO WITH WIRING
104	5013251401	TCO WITH WIRING
105	5513214661	CAM SLIDER