




















66
















85
SERIE TUBI
TUBE SERIES



SERIE TUBI CON BOCCOLE
TUBE SERIES WITH BUSHES



Position	Code	description
000A	5513211891	SCRAPER BRUSH WITH BRISTLES
000B	AS00006031	GRINDER FINGER STOP RING
000C	AS00000378	ECOMULTICLEAN 10ML VIAL
000D	6013211721	PLATE
000Z	AS00010041	FROTHER TUBE
001	5313221031	GROUND COFFEE TANK COVER
002	5513234921	COVER ASSEMBLY
003	AS13200264	UPPER COVER
004	5913212611	GRIND REGULATION KNOB
005	5513222561	REAR PANEL
006	5513217011	LEFT SIDE
007	AS00001792	COFFEE BEANS TANK
008	53132C8134	MEASURING SPOON
009	AS00006115	SWITCH HOLDER
010	5513217001	RIGHT SIDE
011	5313251441	COVER
012	AS13200250	TANK
012A	AS00010091	WATER TANK
013	5313268241	FRONT PIECE
014	AS13200103	COFFEE GROUNDS CONTAINER
015	5313218521	FRONT PIECE
0016	AS00010248	CUP HOLDER
017	AS13200099	DRIP TRAY
018	5313222641	FLOAT
019	5113211621	SWITCH (16A 125/250V)
020	5013211661	POWER SUPPLY CORD WITH PLUG (JP)
021	5313213551	DRAIN TRAY
024	5313224551	BOTTOM OF COVER
025	AS13200301	CONTROL PANEL ASSEMBLY WITHOUT BOARD
026	AS00000612	DISPLAY PCB
027	5313213911	COFFEE OUTLET TANK COVER
029	6132106200	SPRING
030	5332227400	REGULATOR
031	7313246311	COFFEE DISPENSER
033	5313217741	O-RING (D=6.75 T=1.78)
034	9812631250	SCREW (3.5X12)
035	AS13200086	STEAM VALVE ASSEMBLY

036	AS00008493	DLS-KNOB STEAM CHROMED+SPRING(AISI) ECAM
037	AS00009033	COVER
038	AS00006121	TUBE WITH FROTHER
039	53132D0730	O RING
040	5313217751	O-RING BLACK (D=6.07 T=1.78)
041	5332169300	LOWER TUBE
042	5313221171	FROTHER EXTERNAL TUBE
043	5313259621	LEFT FRAME
044	AS00006012	TROLLEY SUPPORT
045	53132C7925	MOBILE FUNNEL
046	5313213371	PISTON LOWERING FLAP
047	AS00008952	REED SENSOR
048	5213228061	POWER BOARD (SW1.0.0 100V)
049	5313224721	RUBBER FOOT PAD
050	5313213841	FROTHER STOP
051	6113210201	SPRING
052	5313259611	RIGHT FRAME
052A	AS00006028	RIGHT FRAME
053	5313213391	EXPULSION ARM
054	7313251451	INFUSER
055	6113210131	SPRING
056	5313213241	EXPULSION LEVER RUBBER PAD
057	5313213191	EXPULSION LEVER
058	9812631250	SCREW (3.5X12)
059	6013213181	FILTER (D.40X2.3 TAI-FENG)
060	5313277681	STOPPER
061	53132C9532	FROTH DEVICE VALVE NATURAL(PSU)ESAM&ECAM
062	6132112200	SPRING
063	5313238581	GASKET
064	6113210181	SPRING
065	5313213411	DOOR
066	7313225081	GRINDER ASSEMBLY (3D-DL 100V)
067	5313224561	INNER COVER
070	9812631250	SCREW (3.5X12)
071	5313213591	TROLLEY SLEWING RING
072	AS00006298	TROLLEY

073	7313295821	COMPENSATION SYSTEM
074	5313213431	GASKET
075	7313250401	DRIVE ASSEMBLY (CHIAPHUA 100V)
076	5213220651	MOTOR BOARD (CHIAPHUA 100V)
077	5132110500	MICROSWITCH (250V 85°)
078	7313257031	MOTOR
079	5213213981	HALL SENSOR (L780)
080	5313243071	TOOTHED BELT
081	5313236711	RIGHT ANGLE WATER OUTLET TUBE (90° L=190)
082	5132104100	MICROSWITCH (250V 85°)
084	5313217601	BLACK FILTER
085	5513227961	MECHANICS VALVE (DLS ECAM)
086A	5313217861	TUBE (DI=3 DE=5,5 L145)
086B	5313217871	TUBE (DI=3 DE=6 L200)
086C	534781	TUBE (L170)
087A	5513212871	TUBE WITH 2 BUSHES (L97)
087B	5513212881	TUBE WITH 2 BUSHES (L270)
087C	5513212891	TUBE WITH 2 BUSHES (L230)
087D	5513212901	TUBE WITH 2 BUSHES (L290)
088	5313217701	O-RING (D=3.85 T=2)
089	6132101300	SPRING
090	5113211301	PUMP
091	5513230831	FLOW REGULATOR
092	5313230671	PUMP SUPPORT
093	5213211181	SENSOR (NTC)
094	5332239300	SPACER
095	5313228791	GENERATOR GASKET
096	6113213191	CLIP (WIRE 1,2 AISI302)
097	5513225871	SAFETY VALVE
098	5113210211	MICROSWITCH
099	5213225251	FLOWMETER
100	5332239200	CONNECTOR
101	5213211161	PUMP PROTECTOR
102	5513216451	ROUND GENERATOR (R1200W100V F6.3)
103	5013255461	TCO WITH WIRING
104	5013256291	WIRING TCO
105	5513214661	CAM SLIDER
106	5313256701	GENERATOR COVER

107

5013251461

WIRING FOR FLOWMETER (L300)