











← TO PLACE AN ORDER CHECK THE LABEL

$AB=62B$




71

-72

64




—66




92




-93



94



95



—67

-74

63-


65

63-

○—63


69-

—70



76

75



78-




—79

 ≥ 80 81—82—


83—1

—84



91

68B



73

88B

53



50

Position	Code	description
000A	7313217261	MOTOR WITH PULLEY (ECM 230V)
000B	5313210401	FINGER STOP COVER (B)
000C	5332224100	MOTOR BELT
000D	5313215891	SCUFF-PROOF RUBBER PAD
000E	5332213100	SPACER
000F	5513211891	SCRAPER BRUSH WITH BRISTLES
000G	6913210021	SOLENOID VALVE SUPPORT (2V)
000H	6913210031	SOLENOID VALVE SUPPORT (3V)
000I	SER0354	GREASE TUBE (5GR VERKOFOOD)
000J	IT1000	PORTABLE DIGITAL THERMOMETER (-50°C +150°C)
000K	AS00000378	ECOMULTICLEAN 10ML VIAL
001	5332187300	COVER
002	5332187200	COVER
004	7313224481	UPPER COVER
005	5332187500	LEFT SIDE
006	5913210471	GRINDING ADJUSTMENT KNOB
007	5532146600	TANK
008	5332187600	REAR PANEL
009	5332187400	RIGHT SIDE
010	5532132000	CONTROL PANEL
011	NOCODE04	SEE TECHNICAL BULLETIN
012	7313220561	DOOR ASSEMBLY
013	5332142600	HOOK
014	5313251471	COVER
015	AS13200251	WATER TANK
016	5332203200	PROFILE
017	6032107700	CUP HOLDER
018	5332213400	CUP HOLDER TRAY
019	5332225800	BOTTOM
020	5332266300	FLOAT
021	53132C8134	MEASURING SPOON
027	5513212881	TUBE WITH 2 BUSHES (L270)
028	6132101300	SPRING
030	5032526900	TCO WITH WIRING
0031	5313284261	SUPPORT
032	5132104100	MICROSWITCH (250V 85°)

033	6132104700	SPRING (x micro 12 x 5)
034	5217100200	SENSOR (NTC L400)
035	7313219431	SAFETY VALVE
036B	5232109800	POWER BOARD (230V)
037	5332225700	SUPPORTO
038	5113270612	PUMP (230V)
039	5232103200	PROTECTOR
041	AS13200153	VALVE ASSEMBLY WITH FROTHER
042	5532135400	STEAM REGULATION KNOB
044	5232114200	ELECTRONIC CONTROL BOARD
045	5313217761	O-RING (D=5.28 T=1.78)
046	533135	GASKET (D=7,66 T=1,78)
047	5332113800	LOWER TUBE
048	5332197200	PUSH BUTTON
049	5332229600	COVER
050	5113210421	MICROSWITCH
050A	5132105400	MICROSWITCH (10A/ 250V/ 125°)
051	5513220521	IMPURITY FILTER
053	5213213971	HALL SENSOR (L620)
054	5213225251	FLOWMETER
055	5232104600	REED SENSOR
062B	5513227971	GRINDER ASSEMBLY (2D-DL 230V)
063	5313217751	O-RING BLACK (D=6.07 T=1.78)
064	7332196800	GENERATOR
065	5332213000	PIN
066	5313276531	GASKET
067	5332139200	FILTER
068B	5513227951	TRANSMISSION ASSEMBLY (CHIAPHUA 230V)
069	5332148400	VALVE
070	6132106900	SPRING
071	5332142300	BUSH
072	5332142400	BUSH
073	AS00009034	TOOTHED BELT
074	5332149100	O-RING
075	6132103500	SPRING
076	5332139800	LEVER
077	7313251441	INFUSER
078	9812631250	SCREW (3.5X12)

079	6013213181	FILTER (D.40X2.3 TAI-FENG)
081	5313277681	STOPPER
082	53132C9532	FROTH DEVICE VALVE NATURAL(PSU)ESAM&ECAM
083	6132106700	SPRING
084	5332140300	PISTON
088B	5213212381	MOTOR BOARD (ECM 230V)
089	5332203400	COVER
090	534848	SUPPORT
091	7332166600	SLIDER
092	5232105000	SAFETY THERMOSTAT (13.5A 318°)
093	5232104500	SAFETY THERMOSTAT (16A 170°)
094	5513225701	SOLENOID VALVE KIT (2VA 230V)
095	NOCODE04	SEE TECHNICAL BULLETIN
096	5332195000	GLASS
097	5932124500	FRONT PIECE
099	5332194900	COVER
100	5332195300	KEYBOARD
101	5932116000	KEY
102	5932116100	KEY
103	5932116200	PUSH BUTTON
104	5932116300	KEY
105	5932117200	KEY