










Position	Code	description
00BE	AS00000378	ECOMULTICLEAN 10ML VIAL
00BF	5332186200	DRAIN HOSE (90°L180)
00BG	5313283911	TUBE
00BH	5332115400	SILICONE HOSE (DI=5 L=145)
00BI	5313283721	TUBE (DI=7 DE=10 L=120)
00BJ	5313249311	SILICONE HOSE (DI=3 DE=5,5 L15)
00BK	6913210111	FRONT BRACKET DEGREASED ESAM69
0AAA	5132112500	SWITCH
0AAB	5332283000	DISPENSER GLASS
0ABA	5132112500	SWITCH
0ABB	5332108700	GASKET
0ACA	5332108700	GASKET
0ACB	5032514800	FLOWMETER WIRING (L 470)
0ADA	5032514800	FLOWMETER WIRING (L 470)
0ADB	5332186200	DRAIN HOSE (90°L180)
0AEA	5313210401	FINGER STOP COVER (B)
0AEB	5332224100	MOTOR BELT
0AFA	5332224100	MOTOR BELT
0AFB	5332238300	DRAIN HOSE (90° L=180)
0AGA	AS13200107	COVER ASSEMBLY
0AGB	5332164700	RUNNER FRAME
0AHA	5332164700	RUNNER FRAME
0AHB	5013252911	WIRING FOR FLOWMETER (L630)
0AIA	5013252911	WIRING FOR FLOWMETER (L630)
0AIB	5313211301	BLACK REAR PANEL CAP
0AJA	5313211301	BLACK REAR PANEL CAP
0AJB	5313215891	SCUFF-PROOF RUBBER PAD
0AKA	5313215891	SCUFF-PROOF RUBBER PAD
0AKB	5913210181	SELECTOR KEY
0ALA	5332283000	DISPENSER GLASS
0ALB	6113210111	FIXING BRACKET (TCO)
0AMA	5513211891	SCRAPER BRUSH WITH BRISTLES
0AMB	6113210121	SENSOR BRACKET
0ANA	5913210181	SELECTOR KEY
0ANB	5913212241	LEFT FUNCTION KEYBOARD
0AOA	6113210111	FIXING BRACKET (TCO)
0AOB	5913210371	FUNCTION KEYBOARD

0APA	6113210121	SENSOR BRACKET
0APB	6932102800	BRACKET
0AQA	5913212241	LEFT FUNCTION KEYBOARD
0AQB	6913210021	SOLENOID VALVE SUPPORT (2V)
0ARA	5913210371	FUNCTION KEYBOARD
0ARB	6913210031	SOLENOID VALVE SUPPORT (3V)
0ASA	5313219181	GRINDER BELLOW GASKET
0ASB	6913210011	POD SUPPORT
0ATA	6932102800	BRACKET
0ATB	5332286300	HANDLE
0AUA	5332238300	DRAIN HOSE (90° L=180)
0AUB	6913210021	SOLENOID VALVE SUPPORT (2V)
0AVA	6913210031	SOLENOID VALVE SUPPORT (3V)
0AVB	AS13200107	COVER ASSEMBLY
0AWA	5313219181	GRINDER BELLOW GASKET
0AWB	6913210011	POD SUPPORT
0AXA	SER0354	GREASE TUBE (5GR VERKOFOOD)
0AXB	5313239751	GRINDER PANEL
0AYA	5313239751	GRINDER PANEL
0AYB	5332286300	HANDLE
0AZA	6932104400	GRID
0AZB	IT1000	PORTABLE DIGITAL THERMOMETER (-50°C +150°C)
0BAA	IT1000	PORTABLE DIGITAL THERMOMETER (-50°C +150°C)
0BAB	5332261200	GASKET
0BBA	5513211891	SCRAPER BRUSH WITH BRISTLES
0BBB	AS00000378	ECOMULTICLEAN 10ML VIAL
0BCA	6932104400	GRID
0BCB	5313210591	RING SELECTOR CHROME (4E)MCSA
0BDA	5313210591	RING SELECTOR CHROME (4E)MCSA
0BDB	6913210111	FRONT BRACKET DEGREASED ESAM69
1	5332278100	TANK COVER
2	53132C8052	TOP COVER
3	5332226300	MEASURING SPOON
4	5332278400	LEFT SIDE
5	7313224431	UPPER COVER
6	5332278600	REAR PANEL

7	535714	STOPPER
8	5313211001	GRINDING ADJUSTMENT KNOB
9	5532145700	TANK
10	5313251461	TANK COVER
11	7313223101	CONTROL PANEL ASSEMBLY
12	7313224941	DOOR ASSEMBLY
13	5313222761	FROTHER NICHE
14	5332282300	FRONT PIECE
15	5332282100	SUPPORT
16	5332282200	SUPPORT
17	7313254531	WATER TANK
18	5332278300	RIGHT SIDE
19	6032120800	CUP HOLDER
20	5332266600	FLOAT
21	NOCODE04	SEE TECHNICAL BULLETIN
22	5332225000	BOTTOM
23	5332283900	DRIP TRAY
29	5513211001	CONTROL BOARD
30	6013213181	FILTER (D.40X2.3 TAI-FENG)
31	5332149100	O-RING
32	7313251441	INFUSER
033A	5013251191	TCO WITH WIRING
033B	5013251201	TCO WITH WIRING
34	7313216831	GRINDER ASSEMBLY (2D-DL 120V)
0035	5313284261	SUPPORT
36	6132104700	SPRING (x micro 12 x 5)
37	5132105700	MICROSWITCH
38	7332166600	SLIDER
39	5332142400	BUSH
40	5332142300	BUSH
41	5217100200	SENSOR (NTC L400)
42	5313217751	O-RING BLACK (D=6.07 T=1.78)
43	5332213000	PIN
44	5332148400	VALVE
45	6132106900	SPRING
46	5313276531	GASKET
47	5332139200	FILTER
48	7313213951	GENERATOR WITH MECHANICS VALVE (5X0.5

120V BR)

49	5113210421	MICROSWITCH
50	5132110500	MICROSWITCH (250V 85°)
51	5213213971	HALL SENSOR (L620)
52	5313243071	TOOTHED BELT
53	AS00005902	TRANSMISSION ASSEMBLY (ECM 120V)
54	6132101300	SPRING
55	5313217701	O-RING (D=3.85 T=2)
56	5313216501	PUMP SUPPORT
57	7313219431	SAFETY VALVE
58	5232103200	PROTECTOR
59	5113211291	PUMP (ULKA 120V 52W)
60	534848	SUPPORT
61	5232104600	REED SENSOR
62	5213210961	POWER BOARD (SW1.1 120V)
63	5132105400	MICROSWITCH (10A/ 250V/ 125°)
64	5332196900	CONNECTION
66	5513225741	SOLENOID VALVE KIT (2VA 120V)
67	5332196800	CONNECTION
71	NOCODE04	SEE TECHNICAL BULLETIN
072	5213225251	FLOWMETER
73	5513219841	TUBE WITH NUT AND 1 BUSH (L135)
75	5332188800	CONNECTION
76	5513213501	TUBE WITH 2 BUSHES (L150)
77	6113213191	CLIP (WIRE 1,2 AISI302)
78	5332239200	CONNECTOR
79	5313217761	O-RING (D=5.28 T=1.78)
80	5513220521	IMPURITY FILTER
81	5532151500	TUBE
82	5332142600	HOOK
83	5332180500	CONNECTION
84	535692	GASKET
85	5513225741	SOLENOID VALVE KIT (2VA 120V)
87	5313219781	SOLENOID VALVE SUPPORT
88	5332144800	O-RING (D=6)
89	5513213401	FROTHER TUBE
90	535692	GASKET
91	533135	GASKET (D=7,66 T=1,78)

92	AS00008426	TUBE
94	5332139800	LEVER
95	6132103500	SPRING
96	9812631250	SCREW (3.5X12)
97	5313277681	STOPPER
98	5313268011	VALVE
99	6132106700	SPRING
100	9824800009	CLIP CLAMP (8.30-8.10-7.80)
101	5313216541	A T CONNECTION (PRES BLOCK)
102	5332169300	LOWER TUBE