








TEST LABEL











TEST LABEL













TO PLACE AN ORDER CHECK THE LABEL

CCCCC **EE** SSSSS PPPP


AB=62B



64





77




91


68B



73



88B



Position	Code	description
00BB	5332186200	DRAIN HOSE (90°L180)
00BC	5313249311	SILICONE HOSE (DI=3 DE=5,5 L15)
00BD	6913210111	FRONT BRACKET DEGREASED ESAM69
0AAA	5332108700	GASKET
0AAB	5332108700	GASKET
0ABA	7313217261	MOTOR WITH PULLEY (ECM 230V)
0ABB	7313217261	MOTOR WITH PULLEY (ECM 230V)
0ACA	5032514800	FLOWMETER WIRING (L 470)
0ACB	5032514800	FLOWMETER WIRING (L 470)
0ADA	5313210401	FINGER STOP COVER (B)
0ADB	5332186200	DRAIN HOSE (90°L180)
0AEA	5332224100	MOTOR BELT
0AEB	5332224100	MOTOR BELT
0AFA	5332238300	DRAIN HOSE (90° L=180)
0AFB	5332164700	RUNNER FRAME
0AGA	AS13200107	COVER ASSEMBLY
0AGB	5013252911	WIRING FOR FLOWMETER (L630)
0AHA	5313226131	SWITCH HOLDER
0AHB	5313211301	BLACK REAR PANEL CAP
0AIA	5332164700	RUNNER FRAME
0AIB	5313215891	SCUFF-PROOF RUBBER PAD
0AJA	5013252911	WIRING FOR FLOWMETER (L630)
0AJB	6113210111	FIXING BRACKET (TCO)
0AKA	5313211301	BLACK REAR PANEL CAP
0AKB	6113210121	SENSOR BRACKET
0ALA	5313215891	SCUFF-PROOF RUBBER PAD
0ALB	6932102800	BRACKET
0AMA	5332227200	DISPENSER GLASS
0AMB	6913210021	SOLENOID VALVE SUPPORT (2V)
0ANA	5513211891	SCRAPER BRUSH WITH BRISTLES
0ANB	6913210031	SOLENOID VALVE SUPPORT (3V)
0AOA	6113210111	FIXING BRACKET (TCO)
0AOB	6913210011	POD SUPPORT
0APA	5313226131	SWITCH HOLDER
0APB	6113210121	SENSOR BRACKET
0AQA	5313242831	TANK PRESENCE CAM
0AQB	5313242831	TANK PRESENCE CAM

0ARA	5332238300	DRAIN HOSE (90° L=180)
0ARB	5313219181	GRINDER BELLOW GASKET
0ASA	6932102800	BRACKET
0ASB	AS13200107	COVER ASSEMBLY
0ATA	5313219181	GRINDER BELLOW GASKET
0ATB	6913210021	SOLENOID VALVE SUPPORT (2V)
0AUA	5332227200	DISPENSER GLASS
0AUB	6913210031	SOLENOID VALVE SUPPORT (3V)
0AVA	6913210011	POD SUPPORT
0AVB	5313239751	GRINDER PANEL
0AWA	5313239751	GRINDER PANEL
0AWB	IT1000	PORTABLE DIGITAL THERMOMETER (-50°C +150°C)
0AXA	SER0354	GREASE TUBE (5GR VERKOFOOD)
0AXB	IT1000	PORTABLE DIGITAL THERMOMETER (-50°C +150°C)
0AYA	AS00000378	ECOMULTICLEAN 10ML VIAL
0AYB	5332261200	GASKET
0AZA	5513211891	SCRAPER BRUSH WITH BRISTLES
0AZB	6913210111	FRONT BRACKET DEGREASED ESAM69
0BAA	AS00000378	ECOMULTICLEAN 10ML VIAL
0BAB	5313283931	TUBE (SIL PLAT DI=5 DE=8 L=145)
A	5313283911	TUBE
B	5332110600	TUBE (DI=4 L=220)
C	5332150700	SILICONE HOSE (DI=4 L=55)
D	5332115400	SILICONE HOSE (DI=5 L=145)
E	5332177800	SILICONE HOSE (DI=4 L=200)
F	5313283721	TUBE (DI=7 DE=10 L=120)
G	5513213501	TUBE WITH 2 BUSHES (L150)
H	5513219841	TUBE WITH NUT AND 1 BUSH (L135)
I	5513219851	TUBE WITH NUT AND 1 BUSH (L335)
L	5513213801	TUBE WITH 2 BUSHES (L180)
M	5513212881	TUBE WITH 2 BUSHES (L270)
1	AS00000705	COVER
2	AS00004434	COVER
4	AS00000706	CLOSURE
5	AS00002742	LEFT SIDE
6	5313210961	GRINDING ADJUSTMENT KNOB

7	5532145700	TANK
8	5332228000	REAR PANEL
9	AS00003968	RIGHT SIDE
10	7313216891	CONTROL PANEL FRONT PIECE
11	NOCODE04	SEE TECHNICAL BULLETIN
12	7313223291	DOOR ASSEMBLY
13	5332142600	HOOK
14	5313251481	WATER TANK COVER
15	AS13200255	WATER TANK
16	AS00001341	PROFILE
17	7032115100	CUP HOLDER
18	5332246200	CUP HOLDER TRAY
19	5332225000	BOTTOM
20	5332266300	FLOAT
21	5332226300	MEASURING SPOON
22	5932120300	KEY
23	5332238000	KEY
24	5313234681	FUNCTION KEYBOARD
25	NOCODE04	SEE TECHNICAL BULLETIN
26	5313235801	RUNNER
27	5513219851	TUBE WITH NUT AND 1 BUSH (L335)
28	6132101300	SPRING
29	5332237800	KEY
30	5032526800	TCO WITH WIRING
0031	5313284261	SUPPORT
32	5132104100	MICROSWITCH (250V 85°)
33	6132104700	SPRING (x micro 12 x 5)
34	5217100200	SENSOR (NTC L400)
35	7313219431	SAFETY VALVE
036B	NOCODE04	SEE TECHNICAL BULLETIN
37	5313216501	PUMP SUPPORT
38	5113270612	PUMP (230V)
39	5232103200	PROTECTOR
40	5513212881	TUBE WITH 2 BUSHES (L270)
43	5113210421	MICROSWITCH
44	NOCODE04	SEE TECHNICAL BULLETIN
050A	5132105400	MICROSWITCH (10A/ 250V/ 125°)
50	5113210421	MICROSWITCH

51	5513220521	IMPURITY FILTER
52	NOCODE04	SEE TECHNICAL BULLETIN
53	5213213971	HALL SENSOR (L620)
054	5213225251	FLOWMETER
55	5232104600	REED SENSOR
062B	5513227971	GRINDER ASSEMBLY (2D-DL 230V)
63	5313217751	O-RING BLACK (D=6.07 T=1.78)
64	NOCODE04	SEE TECHNICAL BULLETIN
65	5332213000	PIN
66	5313276531	GASKET
67	5332139200	FILTER
068B	5513227951	TRANSMISSION ASSEMBLY (CHIAPHUA 230V)
69	5332148400	VALVE
70	6132106900	SPRING
71	5332142300	BUSH
72	5332142400	BUSH
73	5313243071	TOOTHED BELT
74	5332149100	O-RING
75	6132103500	SPRING
76	5332139800	LEVER
77	7313251441	INFUSER
078	9812631250	SCREW (3.5X12)
79	6013213181	FILTER (D.40X2.3 TAI-FENG)
80	5332149100	O-RING
81	5313277681	STOPPER
82	5313268011	VALVE
83	6132106700	SPRING
84	5332140300	PISTON
088B	5213212381	MOTOR BOARD (ECM 230V)
89	5332246000	COVER
90	534848	SUPPORT
91	7332166600	SLIDER
92	5232105000	SAFETY THERMOSTAT (13.5A 318°)
94	5513225711	SOLENOID VALVE KIT (3VA 230V)
95	NOCODE04	SEE TECHNICAL BULLETIN
105	5313217701	O-RING (D=3.85 T=2)
107A	5513211641	MILK CARAFE PRIMADONNA ESAM AND EABI
108A	5513211641	MILK CARAFE PRIMADONNA ESAM AND EABI

109	5313252051	SOLENOID VALVE SUPPORT
110	5513225701	SOLENOID VALVE KIT (2VA 230V)
111	AS13200286	CARAFE COUPLING
112	5513212801	HOT WATER SPOUT