

























TEST LABEL






TO PLACE AN ORDER CHECK THE LABEL

CCCCC **EE** SSSSS PPPP

AB=62B



68B



Position	Code	description
00AA	5332108700	GASKET
00AB	5032514800	FLOWMETER WIRING (L 470)
00AC	5313210401	FINGER STOP COVER (B)
00AD	5332186200	DRAIN HOSE (90°L180)
00AE	5332224100	MOTOR BELT
00AF	5332238300	DRAIN HOSE (90° L=180)
00AG	AS13200107	COVER ASSEMBLY
00AH	5332164700	RUNNER FRAME
00AI	5013252911	WIRING FOR FLOWMETER (L630)
00AJ	5313211301	BLACK REAR PANEL CAP
00AK	5313215891	SCUFF-PROOF RUBBER PAD
00AL	5332227200	DISPENSER GLASS
00AM	5513211891	SCRAPER BRUSH WITH BRISTLES
00AN	6113210111	FIXING BRACKET (TCO)
00AO	6113210121	SENSOR BRACKET
00AP	5313242831	TANK PRESENCE CAM
00AQ	5313219181	GRINDER BELLOW GASKET
00AR	6932102800	BRACKET
00AS	6913210021	SOLENOID VALVE SUPPORT (2V)
00AT	6913210031	SOLENOID VALVE SUPPORT (3V)
00AU	SER0354	GREASE TUBE (5GR VERKOFOOD)
00AV	6913210011	POD SUPPORT
00AW	5313239751	GRINDER PANEL
00AX	IT1000	PORTABLE DIGITAL THERMOMETER (-50°C +150°C)
00AY	5313249311	SILICONE HOSE (DI=3 DE=5,5 L15)
00AZ	5313240551	TUBE (SIL PLAT)DI=3 DE=5.5 L17
00BA	AS00000378	ECOMULTICLEAN 10ML VIAL
00BB	5313283721	TUBE (DI=7 DE=10 L=120)
00BC	5332261200	GASKET
00BD	5313283911	TUBE
00BE	6913210111	FRONT BRACKET DEGREASED ESAM69
00BF	5313283931	TUBE (SIL PLAT DI=5 DE=8 L=145)
A	5313283911	TUBE
B	5332110600	TUBE (DI=4 L=220)
C	5332150700	SILICONE HOSE (DI=4 L=55)
D	5332115400	SILICONE HOSE (DI=5 L=145)

E	5332177800	SILICONE HOSE (DI=4 L=200)
F	5332111500	TUBE (DI=7 DE=10 L=120)
G	5513213501	TUBE WITH 2 BUSHES (L150)
H	5513219841	TUBE WITH NUT AND 1 BUSH (L135)
I	5513219851	TUBE WITH NUT AND 1 BUSH (L335)
L	5513213801	TUBE WITH 2 BUSHES (L180)
M	5513212881	TUBE WITH 2 BUSHES (L270)
001	AS00000705	COVER
002	AS00004434	COVER
004	AS00000706	CLOSURE
005	5532153400	LEFT SIDE
006	5313210961	GRINDING ADJUSTMENT KNOB
007	5532145700	TANK
008	5332228000	REAR PANEL
009	5532153200	RIGHT SIDE
010	7313217151	CONTROL PANEL ASSEMBLY
011	NOCODE04	SEE TECHNICAL BULLETIN
012	7313223291	DOOR ASSEMBLY
013	5332142600	HOOK
014	5313251481	WATER TANK COVER
015	AS13200255	WATER TANK
016	AS00001341	PROFILE
017	7032115100	CUP HOLDER
018	5332246200	CUP HOLDER TRAY
019	5332225800	BOTTOM
020	5332266300	FLOAT
021	5332226300	MEASURING SPOON
025	5213216191	DISPLAY BOARD (SW4.2)
026	5313234681	FUNCTION KEYBOARD
027	5513219851	TUBE WITH NUT AND 1 BUSH (L335)
028	6132101300	SPRING
029	5332237800	KEY
030	5032527700	TCO WITH WIRING
031	5332142200	SUPPORT
032	5132104100	MICROSWITCH (250V 85°)
033	6132104700	SPRING (x micro 12 x 5)
034	5232105100	SENSOR (NTC)
035	7313219431	SAFETY VALVE

036B	5232120100	POWER BOARD (120V)
037	5313216501	PUMP SUPPORT
038	5113211291	PUMP (ULKA 120V 52W)
039	5232102000	PROTECTOR
040	5513212881	TUBE WITH 2 BUSHES (L270)
041	5932120300	KEY
042	5332238000	KEY
043	5132110500	MICROSWITCH (250V 85°)
044	5313235801	RUNNER
050	5132105700	MICROSWITCH
050A	5132105400	MICROSWITCH (10A/ 250V/ 125°)
051	5513220521	IMPURITY FILTER
052	NOCODE04	SEE TECHNICAL BULLETIN
053	5213213971	HALL SENSOR (L620)
054	5213225251	FLOWMETER
055	5232104600	REED SENSOR
062B	NOCODE04	SEE TECHNICAL BULLETIN
063	5313217751	O-RING BLACK (D=6.07 T=1.78)
064	7313213931	GENERATOR WITH MECHANICS VALVE ASSEMBLY (6X1 120V)
065	5332213000	PIN
066	5313276531	GASKET
067	5332139200	FILTER
068B	AS00004230	TRANSMISSION ASSEMBLY (ECM 120V)
069	5332148400	VALVE
070	6132106900	SPRING
071	5332142300	BUSH
072	5332142400	BUSH
073	5313243071	TOOTHED BELT
074	5332149100	O-RING
075	6132103500	SPRING
076	5332139800	LEVER
077	7313251441	INFUSER
078	9812631250	SCREW (3.5X12)
079	6013213181	FILTER (D.40X2.3 TAI-FENG)
080	5332149100	O-RING
081	5313277681	STOPPER
082	53132C9532	FROTH DEVICE VALVE

NATURAL(PSU)ESAM&ECAM

083	6132106700	SPRING
084	5332140300	PISTON
089	5332259200	COVER
090	534848	SUPPORT
091	7332166600	SLIDER
092	5232105000	SAFETY THERMOSTAT (13.5A 318°)
094	5513225801	SOLENOID VALVE KIT (3VA 120V)
095	NOCODE04	SEE TECHNICAL BULLETIN
105	5313217701	O-RING (D=3.85 T=2)
107A	5513211641	MILK CARAFE PRIMADONNA ESAM AND EABI
108A	5513211641	MILK CARAFE PRIMADONNA ESAM AND EABI
109	5313252051	SOLENOID VALVE SUPPORT
110	5513225741	SOLENOID VALVE KIT (2VA 120V)
111	AS13200286	CARAFE COUPLING
112	5513212801	HOT WATER SPOUT
113	5332234800	WATER INTAKE TUBE (L146XD10)