










Position	Code	description
00BE	5313283911	TUBE
00BF	5332115400	SILICONE HOSE (DI=5 L=145)
00BG	5313283721	TUBE (DI=7 DE=10 L=120)
00BH	5313249311	SILICONE HOSE (DI=3 DE=5,5 L15)
00BI	6913210111	FRONT BRACKET DEGREASED ESAM69
0AAA	5332108700	GASKET
0AAB	5332283000	DISPENSER GLASS
0ABA	5332108700	GASKET
0ABB	5332186200	DRAIN HOSE (90°L180)
0ACA	5332224100	MOTOR BELT
0ACB	5032518100	VOLUME METER WIRING (L 470)
0ADA	5332224100	MOTOR BELT
0ADB	5332238300	DRAIN HOSE (90° L=180)
0AEA	7313217271	MOTOR WITH PULLEY (ECM 120V)
0AEB	7313217271	MOTOR WITH PULLEY (ECM 120V)
0AFA	AS13200107	COVER ASSEMBLY
0AFB	5332164700	RUNNER FRAME
0AGA	5332164700	RUNNER FRAME
0AGB	5313211301	BLACK REAR PANEL CAP
0AHA	5313211301	BLACK REAR PANEL CAP
0AHB	5313215891	SCUFF-PROOF RUBBER PAD
0AIA	5313212721	NICHE FRONT PIECE (IFD)
0AIB	5313265471	SPACER
0AJA	5313215891	SCUFF-PROOF RUBBER PAD
0AJB	5913210181	SELECTOR KEY
0AKA	5313265471	SPACER
0AKB	5913210211	KEY (IFD)
0ALA	5332283000	DISPENSER GLASS
0ALB	6113210111	FIXING BRACKET (TCO)
0AMA	5513211891	SCRAPER BRUSH WITH BRISTLES
0AMB	6113210121	SENSOR BRACKET
0ANA	5913210181	SELECTOR KEY
0ANB	5913210191	FUNCTION KEYBOARD
0AOA	5913210211	KEY (IFD)
0AOB	5913212251	FUNCTION KEYBOARD
0APA	6113210111	FIXING BRACKET (TCO)
0APB	6932102800	BRACKET

0AQA	6113210121	SENSOR BRACKET
0AQB	6913210021	SOLENOID VALVE SUPPORT (2V)
0ARA	5913210191	FUNCTION KEYBOARD
0ARB	6913210031	SOLENOID VALVE SUPPORT (3V)
0ASA	5913212251	FUNCTION KEYBOARD
0ASB	5332279100	CONTROL PANEL
0ATA	5032518100	VOLUME METER WIRING (L 470)
0ATB	6913210011	POD SUPPORT
0AUA	5313212721	NICHE FRONT PIECE (IFD)
0AUB	5313219181	GRINDER BELLOW GASKET
0AVA	6932102800	BRACKET
0AVB	5313239751	GRINDER PANEL
0AWA	6913210021	SOLENOID VALVE SUPPORT (2V)
0AWB	5332286300	HANDLE
0AXA	5332238300	DRAIN HOSE (90° L=180)
0AXB	6913210031	SOLENOID VALVE SUPPORT (3V)
0AYA	5332279100	CONTROL PANEL
0AYB	AS13200107	COVER ASSEMBLY
0AZA	5313219181	GRINDER BELLOW GASKET
0AZB	6913210011	POD SUPPORT
0BAA	5313239751	GRINDER PANEL
0BAB	5332261200	GASKET
0BBA	5513211891	SCRAPER BRUSH WITH BRISTLES
0BBB	5332286300	HANDLE
0BCA	AS00000378	ECOMULTICLEAN 10ML VIAL
0BCB	AS00000378	ECOMULTICLEAN 10ML VIAL
0BDA	5332186200	DRAIN HOSE (90°L180)
0BDB	6913210111	FRONT BRACKET DEGREASED ESAM69
1	5332278100	TANK COVER
2	53132C8052	TOP COVER
3	5332226300	MEASURING SPOON
4	5313212911	LEFT SIDE
5	7313224431	UPPER COVER
6	5313212921	REAR PANEL
7	535714	STOPPER
8	5313211001	GRINDING ADJUSTMENT KNOB
9	5532149100	TANK
10	5313251461	TANK COVER

011A	7313223271	CONTROL PANEL ASSEMBLY
011B	7313235721	CONTROL PANEL ASSEMBLY
12	7313223631	DOOR ASSEMBLY
13	5313212891	FROTHER NICHE (IFD)
14	5313210761	TANK FRONT PIECE
15	5332282400	SUPPORT
16	5332282500	SUPPORT
17	7313254531	WATER TANK
18	5313212901	RIGHT SIDE
19	6032120800	CUP HOLDER
20	5332266600	FLOAT
21	NOCODE04	SEE TECHNICAL BULLETIN
22	5332225800	BOTTOM
23	5332283900	DRIP TRAY
25	5513212801	HOT WATER SPOUT
26	5332259800	WATER INTAKE TUBE
27	7313210411	COVER ASSEMBLY
28	7313229411	CARAFE
029A	5513211151	CONTROL BOARD
029B	5513214691	DISPLAY BOARD
32	5132105400	MICROSWITCH (10A/ 250V/ 125°)
33	NOCODE04	SEE TECHNICAL BULLETIN
34	5313276531	GASKET
35	6013213181	FILTER (D.40X2.3 TAI-FENG)
36	5332149100	O-RING
37	7313251441	INFUSER
38	5032527700	TCO WITH WIRING
40	5332142200	SUPPORT
41	6132104700	SPRING (x micro 12 x 5)
42	5132104100	MICROSWITCH (250V 85°)
43	7332166600	SLIDER
44	5332142400	BUSH
45	5332142300	BUSH
46	5232105100	SENSOR (NTC)
47	5313217751	O-RING BLACK (D=6.07 T=1.78)
48	5332213000	PIN
49	5332148400	VALVE
50	6132106900	SPRING

51	5332149100	O-RING
52	5332139200	FILTER
53	NOCODE04	SEE TECHNICAL BULLETIN
55	5132110500	MICROSWITCH (250V 85°)
56	5213213971	HALL SENSOR (L620)
57	5313243071	TOOTHED BELT
58	AS00004230	TRANSMISSION ASSEMBLY (ECM 120V)
60	5313217701	O-RING (D=3.85 T=2)
61	5313216501	PUMP SUPPORT
62	7313219431	SAFETY VALVE
63	5232102000	PROTECTOR
64	5113211291	PUMP (ULKA 120V 52W)
65	534848	SUPPORT
66	5232104600	REED SENSOR
067A	5213210721	POWER BOARD (SW1.1 120V)
067B	5213210931	POWER BOARD (SW1.2 120V)
68	5132104100	MICROSWITCH (250V 85°)
69	6113210751	INSERT
70	6213210351	NUT
71	6213211521	BRASS BUSH
72	6213210091	CONNECTION
73	6113210741	RING
74	NOCODE04	SEE TECHNICAL BULLETIN
75	5232105000	SAFETY THERMOSTAT (13.5A 318°)
76	NOCODE04	SEE TECHNICAL BULLETIN
77	5232105000	SAFETY THERMOSTAT (13.5A 318°)
078	5213225251	FLOWMETER
79	5513219841	TUBE WITH NUT AND 1 BUSH (L135)
80	5313217741	O-RING (D=6.75 T=1.78)
81	5332196900	CONNECTION
82	5513213501	TUBE WITH 2 BUSHES (L150)
83	6132101300	SPRING
84	5332239200	CONNECTOR
85	535692	GASKET
086	5513220521	IMPURITY FILTER
87	5513212881	TUBE WITH 2 BUSHES (L270)
088	6113213191	CLIP (WIRE 1,2 AISI302)
89	5513213501	TUBE WITH 2 BUSHES (L150)

90	5332196800	CONNECTION
91	5513225801	SOLENOID VALVE KIT (3VA 120V)
92	5513219851	TUBE WITH NUT AND 1 BUSH (L335)
93	5513225741	SOLENOID VALVE KIT (2VA 120V)
95	5332196000	O-RING
96	AS13200286	CARAFE COUPLING
97	5313217751	O-RING BLACK (D=6.07 T=1.78)
98	5332177500	O-RING
100	9824800009	CLIP CLAMP (8.30-8.10-7.80)
101	5313216541	A T CONNECTION (PRES BLOCK)
102	5332142600	HOOK
113	6132103500	SPRING
114	5332139800	LEVER
115	9812631250	SCREW (3.5X12)
116	5313277681	STOPPER
117	5313268011	VALVE
118	6132112200	SPRING
119	5332140300	PISTON
120	5313252051	SOLENOID VALVE SUPPORT
121	AS00007977	DISPENSING TUBE
122	5332144800	O-RING (D=6)