













Position	Code	description
00BD	5313249311	SILICONE HOSE (DI=3 DE=5,5 L15)
00BE	6913210111	FRONT BRACKET DEGREASED ESAM69
0AAA	5332110600	TUBE (DI=4 L=220)
0AAB	5313226131	SWITCH HOLDER
0ABA	7313217261	MOTOR WITH PULLEY (ECM 230V)
0ABB	7313217261	MOTOR WITH PULLEY (ECM 230V)
0ACA	5032514800	FLOWMETER WIRING (L 470)
0ACB	5032514800	FLOWMETER WIRING (L 470)
0ADA	5332186200	DRAIN HOSE (90°L180)
0ADB	5332224100	MOTOR BELT
0AEA	5332224100	MOTOR BELT
0AEB	5332164700	RUNNER FRAME
0AFA	5332238300	DRAIN HOSE (90° L=180)
0AFB	5013252911	WIRING FOR FLOWMETER (L630)
0AGA	AS13200107	COVER ASSEMBLY
0AGB	5313211301	BLACK REAR PANEL CAP
0AHA	5313226131	SWITCH HOLDER
0AHB	5313215891	SCUFF-PROOF RUBBER PAD
0AIA	5332164700	RUNNER FRAME
0AIB	5313218941	GENERATOR SUPPORT
0AJA	5013252911	WIRING FOR FLOWMETER (L630)
0AJB	6113210111	FIXING BRACKET (TCO)
0AKA	AS00008927	POWER SUPPLY CORD WITH PLUG (UK)
0AKB	6113210121	SENSOR BRACKET
0ALA	5313211301	BLACK REAR PANEL CAP
0ALB	6932102800	BRACKET
0AMA	5313215891	SCUFF-PROOF RUBBER PAD
0AMB	6913210021	SOLENOID VALVE SUPPORT (2V)
0ANA	5313218941	GENERATOR SUPPORT
0ANB	6913210031	SOLENOID VALVE SUPPORT (3V)
0AOA	5513211891	SCRAPER BRUSH WITH BRISTLES
0AOB	6913210011	POD SUPPORT
0APA	6113210111	FIXING BRACKET (TCO)
0APB	5313219401	DISPENSER GLASS (ABS) (ESAM67)
0AQA	6113210121	SENSOR BRACKET
0AQB	5313242831	TANK PRESENCE CAM
0ARA	5332238300	DRAIN HOSE (90° L=180)

0ARB	5313242831	TANK PRESENCE CAM
0ASA	5313219181	GRINDER BELLOW GASKET
0ASB	AS13200107	COVER ASSEMBLY
0ATA	6932102800	BRACKET
0ATB	5013211181	POWER SUPPLY CORD WITH PLUG (UK)
0AUA	5313219181	GRINDER BELLOW GASKET
0AUB	6913210021	SOLENOID VALVE SUPPORT (2V)
0AVA	6913210031	SOLENOID VALVE SUPPORT (3V)
0AVB	5313239751	GRINDER PANEL
0AWA	6913210011	POD SUPPORT
0AWB	5332261200	GASKET
0AXA	5513211891	SCRAPER BRUSH WITH BRISTLES
0AXB	5313239751	GRINDER PANEL
0AYA	5313219401	DISPENSER GLASS (ABS) (ESAM67)
0AYB	AS00000378	ECOMULTICLEAN 10ML VIAL
0AZA	5332186200	DRAIN HOSE (90°L180)
0AZB	AS00000378	ECOMULTICLEAN 10ML VIAL
0BAA	5313283721	TUBE (DI=7 DE=10 L=120)
0BAB	5313283911	TUBE
0BBA	5332115400	SILICONE HOSE (DI=5 L=145)
0BBB	6913210111	FRONT BRACKET DEGREASED ESAM69
0BCA	5313283721	TUBE (DI=7 DE=10 L=120)
0BCB	5313283931	TUBE (SIL PLAT DI=5 DE=8 L=145)
1	AS00000705	COVER
2	AS00004434	COVER
3	5332266700	INSERT
4	AS00000706	CLOSURE
5	AS00002742	LEFT SIDE
6	5313210961	GRINDING ADJUSTMENT KNOB
7	5532145700	TANK
8	5332228000	REAR PANEL
9	AS00003968	RIGHT SIDE
10	7313223211	CONTROL PANEL ASSEMBLY
11	NOCODE04	SEE TECHNICAL BULLETIN
12	7313225721	DOOR ASSEMBLY
13	5332142600	HOOK
14	5313251481	WATER TANK COVER
15	AS13200255	WATER TANK

16	AS00004195	WATER TANK FRONT PIECE
17	7032115500	CUP HOLDER
18	5332266500	CUP HOLDER TRAY
19	5332225000	BOTTOM
20	5332266600	FLOAT
21	5332226300	MEASURING SPOON
22	7313211731	COVER
23	7313229411	CARAFE
24	5332266900	FROTHER NICHE
25	5213214811	CONTROL BOARD (SW3.1)
26	AS13200286	CARAFE COUPLING
27	5332259800	WATER INTAKE TUBE
28	5513210251	HOT WATER SPOUT
29	6032118300	CUP HOLDER
30	5532150800	FILTER
32	5132105400	MICROSWITCH (10A/ 250V/ 125°)
33	5513227971	GRINDER ASSEMBLY (2D-DL 230V)
34	5313276531	GASKET
35	6013213181	FILTER (D.40X2.3 TAI-FENG)
36	5332149100	O-RING
37	7313251441	INFUSER
38	5032526800	TCO WITH WIRING
39	5032526900	TCO WITH WIRING
0040	5313284261	SUPPORT
41	6132104700	SPRING (x micro 12 x 5)
42	5132104100	MICROSWITCH (250V 85°)
43	7332166600	SLIDER
44	5332142400	BUSH
45	5332142300	BUSH
46	5217100200	SENSOR (NTC L400)
47	5313217751	O-RING BLACK (D=6.07 T=1.78)
48	5332213000	PIN
49	5332148400	VALVE
50	6132106900	SPRING
51	5332149100	O-RING
52	5332139200	FILTER
53	5513227901	GENERATOR WITH MECHANICS VALVE (5X0.5 230V)

54	5213212381	MOTOR BOARD (ECM 230V)
55	5113210421	MICROSWITCH
56	5213213971	HALL SENSOR (L620)
57	5313243071	TOOTHED BELT
58	5513227951	TRANSMISSION ASSEMBLY (CHIAPHUA 230V)
59	NOCODE04	SEE TECHNICAL BULLETIN
60	5313217701	O-RING (D=3.85 T=2)
61	5313216501	PUMP SUPPORT
62	7313219431	SAFETY VALVE
63	5232103200	PROTECTOR
64	5113270612	PUMP (230V)
65	534848	SUPPORT
66	5232104600	REED SENSOR
67	5213211871	POWER BOARD (SW3.1 230V)
68	5132104100	MICROSWITCH (250V 85°)
69	6113210751	INSERT
70	6213210351	NUT
71	6213211521	BRASS BUSH
72	7013210151	VAPORIZER CONNECTION
73	6113210741	RING
74	NOCODE04	SEE TECHNICAL BULLETIN
75	5232105000	SAFETY THERMOSTAT (13.5A 318°)
77	5232105000	SAFETY THERMOSTAT (13.5A 318°)
078	5213225251	FLOWMETER
79	5513219841	TUBE WITH NUT AND 1 BUSH (L135)
80	5313217741	O-RING (D=6.75 T=1.78)
81	5332196900	CONNECTION
82	5513213501	TUBE WITH 2 BUSHES (L150)
83	6132101300	SPRING
084	5332212900	CONNECTION
85	5313228791	GENERATOR GASKET
086	5513220521	IMPURITY FILTER
87	5513219851	TUBE WITH NUT AND 1 BUSH (L335)
088	6113213191	CLIP (WIRE 1,2 AISI302)
89	5513213501	TUBE WITH 2 BUSHES (L150)
90	5332196800	CONNECTION
91	5513225711	SOLENOID VALVE KIT (3VA 230V)
92	5513219851	TUBE WITH NUT AND 1 BUSH (L335)

93	5513225701	SOLENOID VALVE KIT (2VA 230V)
95	5332196000	O-RING
96	AS13200286	CARAFE COUPLING
97	5313217751	O-RING BLACK (D=6.07 T=1.78)
98	5332177500	O-RING
113	6132103500	SPRING
114	5332139800	LEVER
115	9812631250	SCREW (3.5X12)
116	5313277681	STOPPER
117	5313268011	VALVE
118	6132106700	SPRING
119	5332140300	PISTON
120	5313252051	SOLENOID VALVE SUPPORT