










Position	Code	description
00AA	5332110600	TUBE (DI=4 L=220)
00AB	5332111500	TUBE (DI=7 DE=10 L=120)
00AC	5332115400	SILICONE HOSE (DI=5 L=145)
00AD	5313283911	TUBE
00AE	7313217261	MOTOR WITH PULLEY (ECM 230V)
00AF	5032514800	FLOWMETER WIRING (L 470)
00AG	5313210401	FINGER STOP COVER (B)
00AH	5332186200	DRAIN HOSE (90° L=180)
00AI	5332224100	MOTOR BELT
00AJ	5332238300	DRAIN HOSE (90° L=180)
00AK	AS13200107	COVER ASSEMBLY
00AL	5313226131	SWITCH HOLDER
00AM	5332164700	RUNNER FRAME
00AN	5013252911	WIRING FOR FLOWMETER (L630)
00AO	5313211301	BLACK REAR PANEL CAP
00AP	5313212721	NICHE FRONT PIECE (IFD)
00AQ	5313215891	SCUFF-PROOF RUBBER PAD
00AR	5313265471	SPACER
00AS	5332283000	DISPENSER GLASS
00AT	5513211891	SCRAPER BRUSH WITH BRISTLES
00AU	5913210181	SELECTOR KEY
00AV	5913210211	KEY (IFD)
00AW	6113210111	FIXING BRACKET (TCO)
00AX	6113210121	SENSOR BRACKET
00AY	5913210191	FUNCTION KEYBOARD
00AZ	5913212251	FUNCTION KEYBOARD
00BA	5313219181	GRINDER BELLOW GASKET
00BB	6932102800	BRACKET
00BC	6913210021	SOLENOID VALVE SUPPORT (2V)
00BD	6913210031	SOLENOID VALVE SUPPORT (3V)
00BE	SER0354	GREASE TUBE (5GR VERKOFOOD)
00BF	5332279100	CONTROL PANEL
00BG	6913210011	POD SUPPORT
00BH	5032110800	POWER SUPPLY CORD WITH PLUG (SCHUKO)
00BI	5313239751	GRINDER PANEL
00BJ	5332286300	HANDLE
00BK	6932104400	GRID

00BL	5313249311	SILICONE HOSE (DI=3 DE=5,5 L15)
00BM	5313240551	TUBE (SIL PLAT)DI=3 DE=5.5 L17
00BN	AS00000378	ECOMULTICLEAN 10ML VIAL
00BO	5313210591	RING SELECTOR CHROME (4E)MCSA
00BP	5313283721	TUBE (DI=7 DE=10 L=120)
00BQ	5332261200	GASKET
00BR	5313283911	TUBE
00BS	6913210111	FRONT BRACKET DEGREASED ESAM69
00BT	5313283931	TUBE (SIL PLAT DI=5 DE=8 L=145)
001	5332278100	TANK COVER
002	53132C8052	TOP COVER
003	5332226300	MEASURING SPOON
004	5332278400	LEFT SIDE
005	7313224431	UPPER COVER
006	5332278600	REAR PANEL
007	535714	STOPPER
008	5313211001	GRINDING ADJUSTMENT KNOB
009	5532145700	TANK
010	5313251461	TANK COVER
011	7313223611	CONTROL PANEL ASSEMBLY
012	7313225671	DOOR ASSEMBLY
013	5332278800	FROTHER NICHE
014	5313226101	WATER TANK FRONT PIECE
015	5332282400	SUPPORT
016	5332282500	SUPPORT
017	7313254531	WATER TANK
018	5332278300	RIGHT SIDE
019	6032120800	CUP HOLDER
020	5332266600	FLOAT
021	NOCODE04	SEE TECHNICAL BULLETIN
022	5332225000	BOTTOM
023	5332283900	DRIP TRAY
024	5132112500	SWITCH
025	5513212801	HOT WATER SPOUT
026	5332259800	WATER INTAKE TUBE
027	7313210411	COVER ASSEMBLY
028	7313229411	CARAFE
029	5513214691	DISPLAY BOARD

032	5132105400	MICROSWITCH (10A/ 250V/ 125°)
033	5513227971	GRINDER ASSEMBLY (2D-DL 230V)
034	5313276531	GASKET
035	6013213181	FILTER (D.40X2.3 TAI-FENG)
036	5332149100	O-RING
037	7313251441	INFUSER
038	5032526800	TCO WITH WIRING
039	5032526900	TCO WITH WIRING
0040	5313284261	SUPPORT
041	6132104700	SPRING (x micro 12 x 5)
042	5132104100	MICROSWITCH (250V 85°)
043	7332166600	SLIDER
044	5332142400	BUSH
045	5332142300	BUSH
046	5217100200	SENSOR (NTC L400)
047	5313217751	O-RING BLACK (D=6.07 T=1.78)
048	5332213000	PIN
049	5332148400	VALVE
050	6132106900	SPRING
051	5332149100	O-RING
052	5332139200	FILTER
053	5513227901	GENERATOR WITH MECHANICS VALVE (5X0.5 230V)
054	5213212381	MOTOR BOARD (ECM 230V)
055	5132110500	MICROSWITCH (250V 85°)
056	5213213971	HALL SENSOR (L620)
057	5313243071	TOOTHED BELT
058	5513227951	TRANSMISSION ASSEMBLY (CHIAPHUA 230V)
060	5313217701	O-RING (D=3.85 T=2)
061	5313216501	PUMP SUPPORT
062	7313219431	SAFETY VALVE
063	5232103200	PROTECTOR
064	5113270612	PUMP (230V)
065	534848	SUPPORT
066	5232104600	REED SENSOR
067	5213212691	POWER BOARD (SW2.2 230V)
068	5132104100	MICROSWITCH (250V 85°)
069	6113210751	INSERT

070	6213210351	NUT
071	6213211521	BRASS BUSH
072	6113211331	CONNECTION
073	6113210741	RING
074	NOCODE04	SEE TECHNICAL BULLETIN
075	5232105000	SAFETY THERMOSTAT (13.5A 318°)
076	NOCODE04	SEE TECHNICAL BULLETIN
077	5232105000	SAFETY THERMOSTAT (13.5A 318°)
078	5213225251	FLOWMETER
079	5513219841	TUBE WITH NUT AND 1 BUSH (L135)
080	5313217741	O-RING (D=6.75 T=1.78)
081	5332196900	CONNECTION
082	5513213501	TUBE WITH 2 BUSHES (L150)
083	6132101300	SPRING
084	5332239200	CONNECTOR
085	535692	GASKET
086	5513220521	IMPURITY FILTER
087	5513212881	TUBE WITH 2 BUSHES (L270)
088	6113213191	CLIP (WIRE 1,2 AISI302)
089	5513213501	TUBE WITH 2 BUSHES (L150)
090	5332196800	CONNECTION
091	5513225711	SOLENOID VALVE KIT (3VA 230V)
092	5513219851	TUBE WITH NUT AND 1 BUSH (L335)
093	5513225701	SOLENOID VALVE KIT (2VA 230V)
095	5332196000	O-RING
096	AS13200286	CARAFE COUPLING
097	5313217751	O-RING BLACK (D=6.07 T=1.78)
098	5332177500	O-RING
100	9824800009	CLIP CLAMP (8.30-8.10-7.80)
101	537407	CONNECTION
102	5332142600	HOOK
113	6132103500	SPRING
114	5332139800	LEVER
115	9812631250	SCREW (3.5X12)
116	5313277681	STOPPER
117	53132C9532	FROTH DEVICE VALVE NATURAL(PSU)ESAM&ECAM
118	6132112200	SPRING

119	5332140300	PISTON
120	5313252051	SOLENOID VALVE SUPPORT