













Position	Code	description
00AA	5013252911	WIRING FOR FLOWMETER (L630)
00AB	5013257331	CABLING WITH FUSE (1.25 A)
00AD	5313215891	SCUFF-PROOF RUBBER PAD
00AE	5313219181	GRINDER BELLOW GASKET
00AF	5313239751	GRINDER PANEL
00AG	5313240551	TUBE (SIL PLAT)DI=3 DE=5.5 L17
00AH	5332111500	TUBE (DI=7 DE=10 L=120)
00AI	5332115400	SILICONE HOSE (DI=5 L=145)
00AJ	5332164700	RUNNER FRAME
00AK	5332177900	COVER
00AL	5313283911	TUBE
00AM	5332186200	DRAIN HOSE (90°L180)
00AO	5332215100	GASKET
00AP	5332224100	MOTOR BELT
00AQ	5332238300	DRAIN HOSE (90° L=180)
00AR	5332261200	GASKET
00AS	AS13200107	COVER ASSEMBLY
00AT	5513211891	SCRAPER BRUSH WITH BRISTLES
00AU	6113210111	FIXING BRACKET (TCO)
00AW	6913210011	POD SUPPORT
00AX	6913210111	FRONT BRACKET DEGREASED ESAM69
00AY	6932102800	BRACKET
00AZ	6932103900	GRID
00BA	7313217261	MOTOR WITH PULLEY (ECM 230V)
00BB	AS00000378	ECOMULTICLEAN 10ML VIAL
00BC	IT1000	PORTABLE DIGITAL THERMOMETER (-50°C +150°C)
00BD	SER0354	GREASE TUBE (5GR VERKOFOOD)
0AVA	6113210121	SENSOR BRACKET
0AVB	5032110800	POWER SUPPLY CORD WITH PLUG (SCHUKO)
001	5332187300	COVER
002	5332187200	COVER
003	5332203400	COVER
004	7313227791	UPPER COVER
005	5332187500	LEFT SIDE
006	5913210471	GRINDING ADJUSTMENT KNOB
007	5532146600	TANK

008	5313220261	REAR PANEL
009	5332187400	RIGHT SIDE
011	5313228721	COFFEE GROUNDS CONTAINER
012	7313220561	DOOR ASSEMBLY
013	5332142600	HOOK
014	5313251471	COVER
015	AS13200251	WATER TANK
016	5332203200	PROFILE
017	6032107700	CUP HOLDER
018	5332213400	CUP HOLDER TRAY
019	5332225000	BOTTOM
020	5332266300	FLOAT
021	53132C8134	MEASURING SPOON
022	7313210921	COVER
023	5513218341	TANK
024	5332194900	COVER
025	5213220491	DISPLAY BOARD (SW1.1)
027	5332218900	KEY
028	5532124900	SPOUT
030	5032526900	TCO WITH WIRING
031	5313217701	O-RING (D=3.85 T=2)
032	5132105400	MICROSWITCH (10A/ 250V/ 125°)
033	AS00009946	GRINDER ASSEMBLY
034	5313276531	GASKET
035	6013213181	FILTER (D.40X2.3 TAI-FENG)
036	5332149100	O-RING
037	7313251441	INFUSER
038	5032526800	TCO WITH WIRING
039	5332195300	KEYBOARD
0040	5313284261	SUPPORT
041	6132104700	SPRING (x micro 12 x 5)
042	5132104100	MICROSWITCH (250V 85°)
043	7332166600	SLIDER
044	5332142400	BUSH
045	5332142300	BUSH
046	5217100200	SENSOR (NTC L400)
047	5313217751	O-RING BLACK (D=6.07 T=1.78)
048	5332213000	PIN

INT ESAM4500

MAGNIFICA PRONTO CAPPUCCINO
ESAM4500

049	5332148400	VALVE
050	6132106900	SPRING
051	5332149100	O-RING
052	5332139200	FILTER
053	5513227901	GENERATOR WITH MECHANICS VALVE (5X0.5 230V)
054	5332195000	GLASS
055	5132110500	MICROSWITCH (250V 85°)
056	5213213971	HALL SENSOR (L620)
057	5313243071	TOOTHED BELT
058	5513227951	TRANSMISSION ASSEMBLY (CHIAPHUA 230V)
059	5532134100	CONTROL PANEL
060	5313217701	O-RING (D=3.85 T=2)
061	5313216501	PUMP SUPPORT
062	7313219421	SAFETY VALVE
063	5213211801	PUMP PROTECTOR
064	5113270612	PUMP (230V)
065	534848	SUPPORT
066	5232104600	REED SENSOR
067	5213214971	POWER BOARD (SW1.0 230V)
068	5132104100	MICROSWITCH (250V 85°)
074	5513227931	VAPORIZER (R1000W 230V)
075	5232105000	SAFETY THERMOSTAT (13.5A 318°)
076	5513216731	FRAME WITH RUBBER PADS
077	5232105000	SAFETY THERMOSTAT (13.5A 318°)
078	5213225251	FLOWMETER
079	5513219841	TUBE WITH NUT AND 1 BUSH (L135)
080	5313217741	O-RING (D=6.75 T=1.78)
081	5332196900	CONNECTION
082	5513213501	TUBE WITH 2 BUSHES (L150)
083	6132101300	SPRING
084	5332239200	CONNECTOR
085	535692	GASKET
086	5513220521	IMPURITY FILTER
087	5513212881	TUBE WITH 2 BUSHES (L270)
088	6113213191	CLIP (WIRE 1,2 AISI302)
089	5513213501	TUBE WITH 2 BUSHES (L150)
090	5332196800	CONNECTION

091	5213218471	SOLENOID VALVE
092	5513219851	TUBE WITH NUT AND 1 BUSH (L335)
093	5213218321	SOLENOID VALVE (2VA 230V)
094	5913217571	FRONT PIECE
095	5332196000	O-RING
096	5513227411	CARAFE COUPLING
097	5313217751	O-RING BLACK (D=6.07 T=1.78)
098	5332177500	O-RING
099	5332219000	KEY
100	9824800009	CLIP CLAMP (8.30-8.10-7.80)
101	537407	CONNECTION
102	5332142600	HOOK
103	55132A1659	FLOW REGULATOR
104	5213212381	MOTOR BOARD (ECM 230V)
113	6132103500	SPRING
114	5332139800	LEVER
115	9812631250	SCREW (3.5X12)
116	5313277681	STOPPER
117	53132C9532	FROTH DEVICE VALVE NATURAL(PSU)ESAM&ECAM
118	6132112200	SPRING
119	5332140300	PISTON
120	5313219491	SOLENOID VALVE SUPPORT