









Position	Code	description
0	5313277482	RUBBER PAD
001	AS00007099	UPPER COVER
002	AS00010434	COFFEE BEANS COVER
003	AS00007102	CENTRAL PANEL
004	AS13200344	GROUND COFFEE TANK COVER
006	5913216201	GRIND REGULATION KNOB
007	55132A1346	COFFEE BEANS TANK
008	AS00007105	REAR PANEL
009	5513217011	LEFT SIDE
010	5513220091	HOT WATER SPOUT
015	AS00007107	LEFT FRONT PIECE
016	5013213762	POWER CORD ASSY (CH) PLUG
017	5313263231	DRIP TRAY
018	5313273111	DRIP TRAY GRID
019	6013214711	CUP HOLDER
020	AS00007110	COFFEE GROUNDS CONTAINER
021	5513217001	RIGHT SIDE
022	AS00007113	FRONT PIECE
024	5332227400	REGULATOR
025	6132106200	SPRING
030	5213270906	BOARD
031	5313248181	ON/OFF KEY
032	AS00007115	DISPENSER
033	AS00007117	CONTROL PANEL ASSEMBLY WITH BOARD
034	AS00009990	DLS-COVER TANK SMOKE(C8-11)(SAN) ECAM
036	AS13200312	FRONT PIECE
037	5313213291	HOSE COUPLING COVER
038	5313235921	TANK GASKET
039	5313214981	WATER TANK FILTER
040	6113210251	SPRING
045	AS13200336	WATER TANK ASSEMBLY
046	53132C8134	MEASURING SPOON
048	5313260691	FLOAT
050	5313219181	GRINDER BELLOW GASKET
0052	5513243281	LEFT FRAME
053	AS00007121	MILK CARAFE
055	53132C8204	MILK INTAKE TUBE

057	7313249421	MOTOR ASSEMBLY (CHIAPHUA 230V)
060	5313219181	GRINDER BELLOW GASKET
061	AS13200337	GRINDER ASSEMBLY
063A	5113210211	MICROSWITCH
063B	6113213191	CLIP (WIRE 1,2 AISI302)
064	AS00006025	MICROSWITCH SUPPORT
068	AS00006012	TROLLEY SUPPORT
069	AS00007122	LEFT FRAME
070A	5113210211	MICROSWITCH
070B	7313249421	MOTOR ASSEMBLY (CHIAPHUA 230V)
074	6113210181	SPRING
076	5313229731	RUBBER FOOT PAD
077A	AS00006298	TROLLEY
077B	AS00000614	MOTOR BOARD
078	5513214661	CAM SLIDER
081	7313249421	MOTOR ASSEMBLY (CHIAPHUA 230V)
082	5313243071	TOOTHED BELT
084	5132110500	MICROSWITCH (250V 85°)
085	5213213971	HALL SENSOR (L620)
086	9812631250	SCREW (3.5X12)
087	AS00006742	FIXED DISPENSER SUPPORT
090	AS00005636	TRANSMISSION (CHIAPHUA 230V)
091	6113210181	SPRING
092	5313213411	DOOR
093	7313251451	INFUSER
094	5313213591	TROLLEY SLEWING RING
095	AS00006298	TROLLEY
096	5313213551	DRAIN TRAY
097	5313238581	GASKET
098	5313213391	EXPULSION ARM
099	5313213431	GASKET
100	6013213181	FILTER (D.40X2.3 TAI-FENG)
105A	5313213371	PISTON LOWERING FLAP
105B	AS00006754	GRINDER BELLOW GASKET
106	9812631250	SCREW (3.5X12)
107	53132C7925	MOBILE FUNNEL
108	7313295821	COMPENSATION SYSTEM
110	AS00007123	ELECTRONIC POWER BOARD (LW3 SW1.0.0 230V)

111	AS00007124	RIGHT FRAME
115	5232104600	REED SENSOR
120	5313227841	RIGHT ANGLE DRAIN CONNECTION
121	6132101300	SPRING
122	5313218341	CONNECTION
123	AS00006957	SOLENOID VALVE (3VA 230V)
125	5313217701	O-RING (D=3.85 T=2)
126A	6113213191	CLIP (WIRE 1,2 AISI302)
126B	5513226521	TUBE WITH 2 BUSHES (L250)
130	5513232371	TUBE / 2 BUSHES (PTFE DI2-DE4 L=125)
135	5113210211	MICROSWITCH
137	AS00006027	MECHANICS VALVE (ECAM)
138	5132104100	MICROSWITCH (250V 85°)
139	5313217861	TUBE (DI=3 DE=5,5 L145)
140	5313217601	BLACK FILTER
141	9812631250	SCREW (3.5X12)
143	5513212881	TUBE WITH 2 BUSHES (L270)
144	5513212901	TUBE WITH 2 BUSHES (L290)
145	9812631250	SCREW (3.5X12)
150	5313238351	TUBE (L180)
151	5113213111	WIRED MICROSWITCH
155	AS00006795	FRAME
156	53132D0730	O RING
157A	5132104100	MICROSWITCH (250V 85°)
157B	AS00002588	COFFEE OUTLET TANK COVER
159	AS00006104	CARAFE COUPLING
160	5013258761	WIRING FOR FLOWMETER (L440)
167	6113210181	SPRING
171	5513216521	TUBE WITH 2 BUSHES (L205)
174A	9812631250	SCREW (3.5X12)
174B	5313236711	RIGHT ANGLE WATER OUTLET TUBE (90° L=190)
175	5213225251	FLOWMETER
181A	5313283951	TUBE
181B	AS00006066	TUBE
182	5213211161	PUMP PROTECTOR
183	5113270613	PUMP (230V)
184	5513230831	FLOW REGULATOR
186	5513226131	TUBE WITH 2 BUSHES (L97)

189	6113213191	CLIP (WIRE 1,2 AISI302)
195	5513213501	TUBE WITH 2 BUSHES (L150)
197	5513225902	SAFETY VALVE
198	5313217871	TUBE (DI=3 DE=6 L200)
199	5313256701	GENERATOR COVER
200	5313228791	GENERATOR GASKET
201	5332239300	SPACER
202	5513236251	BOILER (230V)
203	5213211181	SENSOR (NTC)
204	5013256801	TCO WITH WIRING (L710 - L80)
205	5013256811	TCO WITH WIRING (L640 - L130)
206	5332239200	CONNECTOR